
Wireless Charging Power Bank

Instruction Manual MSL-W198Q



Features:

- LED Indicator ON/OFF button
- Micro Input
- Lightning Input
- USB port
- Wireless Input Pad
- Wireless Output Pad



1 x 6000 mAh Power Bank

- 1 x 2-in-1 Charging Cable
- 1 x Instruction Manual

Tech Specifications

· Micro Input: DC 5V 2A

- · Lightning Input: DC 5V 1A
- USB Output 1/2: DC 5V 2A(MAX)
- · Wireless Input: 5V 0.8A
- · Wireless Output: 5V 1A

LED Indicators:

. ON/OFF Button: Press once to to view the remaining power capacity. LED indicator will show Green once the Power bank is on wireless charging standby mode.

Instructions:

- 1. Charging the power bank:
- a. Charge the power bank fully before usage.
- b. Using the built-in 2-in-1 charging cable, insert the USB A port into a certified USB AC adapter or USB port of a computer, insert the 2-in-1 tip (the side with pins
- upwards) into power bank micro input. c. LED indicator will flash BLUE when charging, and will stop once fully charged.
- d. To Wireless Charge the power bank, place power bank(6) on a wireless charging surface.
- device will flash BLUE when charging. 2. Charging mobile phones and other electronic devices: a. Connect the 2-in-1 cable to your mobile
- phone. Android device: The tip with pins upwards; iOS device: The tip without pins upwards. Connect the other end to the power bank it
- will begin to charge automatically. b. Remove the USB cable from your mobile
- device when it is fully charged.
- 3. Charging Mobile phones and other electronic devices with wireless output.
- a. Place wireless charging enable device on Wireless Charging Output Pad(7). The device begins to charge with LED indicator will turn RED.
- b. You can fasten your phone on the power bank via silicone wrap of the power bank(8) during wireless charging.
- * Note: In order to charge devices, use only the accessory cable or the cable included with your own device by the manufacturer.

SAFETY PRECAUTIONS:

- · WARNING-When using this product, basic precautions should always be followed: 1 Read all the instructions before use
- 2. Never store or use this product in temperatures below 32°F (0°C) or above 115°F (45°C).
- 3. Do not overcharge your phone. The unit may become hot under excessive use. Remove your phone once it is fully charged. Never charge your phone for

more than 7 hours at a time

- 4. The unit will only achieve full performance after 2 or 3 completed charge and discharge cycles.
- 5. To reduce the risk of injury, close supervision is required when the product is used near children
- 6. Do not expose the device to moisture.
- 7 Do not use the device in excess of its. output rating. Overload outputs above the rating may result in a risk of fire or injury.
- 8. Do not use the device if damaged or modified
- 9. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire. explosion or risk of injury.
- 10. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
- 11. Do not expose the device to fire or excessive temperatures. Exposure to fire or temperatures above 104°F (40°C) may result in explosion.
- 12. To ensure product safety, ensure that qualified service professionals use only identical replacement parts.
- 13. Attachments on the back of your phone

can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.

ECC WARNING

This device complies with part 15 of the ECC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with

the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one

-- Reorient or relocate the receiving antenna.

or more of the following measures:

- -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator your body: Use only the supplied antenna

