




WHAT'S INCLUDED




180° Camera




Power Adapter



Mounting Screw
& Anchor



(back) (front)
Ball Mount



Camera Stand



Home Security
Sticker

④

SETTING UP YOUR GUARDZILLA

- 1 Download the Guardzilla app to your smartphone.



- 2 Launch the Guardzilla app and follow the set-up instructions.

For additional help go to www.guardzilla.com/support for our step-by-step camera set-up support documents.

⑤

Guardzilla®



Outdoor HD Wi-Fi camera

GO180

SET-UP GUIDE

Practecol, LLC

CAMERA MOUNTING, PLACEMENT & POWERING

POWERING YOUR CAMERA Choosing your power option

- ▶ Plug in the enclosed power cord into the back of your camera and a standard wall outlet.

OR


- ▶ Insert 4 AA batteries into the camera. We recommend lithium batteries. Alkaline batteries will negatively affect camera performance.

GO180

1


Mounting Your Camera On a Wall

- ▶ Fasten the mounting screw into the wall, and hang the magnetic mount from the screw.
- ▶ If you're attaching the ball mount to drywall, be sure to use the plastic drywall anchor that is provided.
- ▶ Place the back of the camera onto the ball mount.
- ▶ Adjust the camera's position as desired.



Hanging Your Camera on the Display Stand

- ▶ Hang the ball mount on the camera stand.
- ▶ Place the camera on the ball mount.
- ▶ Adjust the camera position as desired.



FCC Warning Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.