
WHAT'S INCLUDED



SETTING UP YOUR GUARDZILLA

1 Download the Guardzilla app to your smartphone.





2 Launch the Guardzilla app and follow the set-up instructions.

For additional help go to www.guardzilla.com/support for our step-by-step camera set-up support documents.

www.guardzilla.com Guardzilla is a registered trademark of Practecol, LL0

Guardzilla®



GUARDZILLA 360°
ALL-IN-ONE HD OUTDOOR VIDEO CAMERA
SET-UP GUIDE

CAMERA MOUNTING & PLACEMENT OPTIONS


Placing the Camera on a Flat Surface


To place the camera on a flat surface lower the camera into the enclosed camera stand.



Mounting Your Camera On a Wall or Ceiling


- ▶ Fasten the mounting screw into the wall or ceiling, and hang the magnetic mount from the screw.
- If you're attaching the ball mount to drywall, be sure to use the plastic drywall anchor that is provided.





(2)

- Place the back of the camera onto the ball mount.
- Adjust the camera's position as desired.



Input Rating: 5.3V2A
CAN ICES-3(B)/NMB-3(B)
Manufacturer: Practecol, LLC

Address: 3155 Sutton Blvd, Suite 202, St Louis, MO 63143



FCC Compliance Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the manufacturer could void the user's authority to operate the equipment.

RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body. The device must not be co-located or operating in conjunction with any other antenna or transmitter.

Industry Canada (IC) Compliance Statement:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.