
ENGLISH

Congratulations on your Party 3-in-1 tritan bottle!


This Party 3-in-1 tritan bottle allows you to enjoy your music without wires. Please read this manual carefully before use.

Product descriptions:

1. Volume key - / previous
2. Power switch / pause
3. Volume + / next

Buttons instructions:

- Click the (1 & 3) buttons to skip to previous/next track
- Press and hold (1 & 3) buttons to adjust the volume.
- Click the power button (2) to pause/play or to answer incoming calls. Press and hold the power button (2) to turn off.



How to use:

Step 1: Please charge this product before use. Connect the product to the USB charging cable to charge. The USB input is located on the opposite side of the buttons. When in charging mode, the indicator LED located below the USB input will turn red, and turn off when full charged.

Step 2: Hold power switch (2) to turn on the speaker. The indicator LED located below the USB input will turn in blue (flashing mode) when not connected with Bluetooth.

Step 3: Make sure the Bluetooth mode on your device is switched on.

Step 4: Please select the Bluetooth pairing name "XD_partybottle" in order to pair your mobile device with the speaker.

Once the speaker is turned on, pressing the "-" and "+" buttons (button 1 & 3) at the same time will switch the LED light to the following three different modes: blue (slow) flashing light, white light or light off (no light).

Specifications:

Voltage:	3.4 – 4.2V
Power:	DC 5V/450mA
Bluetooth working range:	Less than 8 meters
Bluetooth pairing name:	XD_partybottle
LED power:	0.2W

Warnings and cautions:

- Do not drop, apply excessive force to the controls, or put heavy objects on top of the speaker.
- Do not attempt to repair, disassemble or modify the product
- If you do not use the speaker for long periods; be sure to store it in a dry place, free from the extreme temperature, humidity and dust.
- Keep speaker away from any heat source.

FCC

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**