



## SOLAR POWERED LED PATH LIGHT SET BLUETOOTH® CONTROLLED

ADVERTENCIA: No deseche las baterías de litio en basureros municipales, arroyos o el fuego, ya que las mismas podrían explotar. No abra, haga cortocircuito ni desarme las baterías. Deseche las baterías siguiendo las regulaciones locales, estatales y federales. No combinar baterías nuevas y viejas. No combine baterías alcalinas, estándar (carbón-zinc) o recargables (níquel cadmio o níquel-metal).

 WESTINGHOUSE, es una marca registrada de Westinghouse Electric Corporation. Usado bajo licencia por Sky Rich Star Limited. Todos los derechos reservados.


iPhone es una marca registrada de Apple Inc. registrada en Estados Unidos y otros países. Android is a trademark of Google Inc. Google Play and the Google Play logo are trademarks of Google Inc.

La marca y el logo Bluetooth® son marcas registradas propiedad de Bluetooth SIG, Inc. y el uso de estas marcas por Sky Rich Star Limited es bajo licencia. Otras marcas registradas y nombres comerciales pertenecen a sus respectivos propietarios. La **Aplicación Westinghouse Smart Landscape** requiere actualizaciones periódicas sin previo aviso.

Para recibir asistencia con el montaje o las instrucciones, repuestos y servicio al cliente,  
llame a: (solo EE.UU. y Canadá) 1-844-551-0680

de 8am – 5pm de lunes a viernes, hora estándar central O envíe un correo electrónico a:  
Customerservice@qx-usa.com

[www.westinghousesolarlights.com](http://www.westinghousesolarlights.com)



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

### Instruction Manual

Model: SR15AA01H-78

## INSTALLATION



1. Prior to installation download the app to ensure phone compatibility. Download the **Westinghouse Smart Landscape App** for free from the App Store or Google Play. You may also scan the QR codes below. Please note that App compatibility is only with iPhone (4 generation or above) and Android™ devices (5.0 or above).



2. Ensure that Bluetooth is enabled on your cellular device and make it discoverable. The way you do this depends on the device. If you need help visit the manufacturer's website to learn how.


3. Path lights include a "Parent" and "Child" light. The light with the large sticker on top is the "Parent". This light also has a reset button located under the solar panel. Only the "parent" light will operate independently. With the solar panels facing down, place each light on a flat surface. This will simulate darkness. The "Parent" light power switch must be turned on first. Next, turn on the "Child" light power switch. It may take 15 to 30 seconds for both lights to illuminate equally.

4. Remove protective film from solar panels and product stickers.



## ASSEMBLY (SOME PARTS MAY COME PRE-ASSEMBLED)




5. Align the tabs on (Part B) with the ledges inside (Part A) and turn (Part A) clockwise until the tabs are secure underneath the ledges. Slide (Part C) over (Part B). Remove the ground stake (Part D) from the bottom of (Part C), flip so that the pointed end is facing outward and reinsert it into the bottom of (Part C). Push the stake into the ground until the top collar is even with the ground surface.



**NOTE: If the ground is hard and packed, moisten the ground with water before inserting the stake to avoid breakage.**

6. Install solar light where it will receive direct sunlight for at least 8 hours each day. Avoid shadowed locations and install away from nighttime light sources which will prohibit the light from working properly.


7. **FOR FIRST TIME USE:** Solar light needs to charge in full sunlight for 8-12 hours with the switch in the "ON" position to allow the rechargeable batteries to reach maximum capacity.



## CAMBIANDO LA BATERÍA


Gire (Parte A) para que se suelte de las repisas. Deslice el interruptor a su posición de "OFF" (apagado). Extraiga los tornillo de la cubierta de la batería con un destornillador Phillips. Tire hacia arriba y retire la cubierta de la batería. Saque la batería agotada y reemplácela con una nueva 3.7V, de litio (18650) 2000 mAh batería recargable. Vuelva a colocar la tapa de la batería retirada anteriormente. Deslice el interruptor a su posición de "ON" (prendido). Reemplace el tono girando en sentido horario hasta que quede seguro.

**Para un rendimiento óptimo, permita que la luz solar se cargue bajo directa luz de sol.**



## INSTRUCCIONES DEL BOTÓN DE RESET


Si usted no puede reiniciar su nombre de usuario y contraseña mediante la App de su teléfono celular, ponga el interruptor de la luz "padre" en la posición "ON" y presione el botón de reinicio de la luz "padre" por al menos 3 segundos hasta que el color de la luz se ponga en rojo. A App le indicará que asigne una nueva contraseña. Ingrese "1234". Pulse el ícono de candado en la pantalla de la App. Seleccione la opción de contraseña que desee y reinicie la contraseña utilizando su propia secuencia numérica. Recuerde que cualquier función previamente almacenada deberá ser reiniciada.



## RESOLUCIÓN DE PROBLEMAS

Si la luz no enciende, retire la batería, limpie ambos extremos con un paño limpio y seco y vuelva a instalar la batería. Revise la batería para asegurarse de que haga contacto con los terminales. Si esto no funciona, reemplácela por una batería nueva.

## AYUDA DE LA APP




## OPERATION

The operational range between your Bluetooth device and the parent light is 26.2ft (8m). The child path light can be installed up to 5m away from the parent path light. The distance depends on the Bluetooth device and environment. Open the App and select *View Tutorial* for instructions or select *Control My Lights* to begin using your lights. The timer function is not available for this path light. To extend runtime, the Bluetooth control is inactive after 4 hours of use. It will resume Bluetooth control the next day once battery is recharged. To over-ride this measure you can turn off and on your lights. This will reduce the runtime until the sun recharges the batteries in your lights.




**Bluetooth**  
26.2ft(8m)

## APP TUTORIAL



## RESET BUTTON INSTRUCTIONS


If you are unable to reset your user name and password using the App on your cell phone, set the “parent” light switch to “ON” position and press the reset button on the “parent” light for at least 3 seconds until the light color turns red. The app will prompt you to assign a new password. Enter “1234”. Tap the lock icon on the app screen. Select desired password option and reset the password using your own number sequence. Note that any previously saved functions will need to be reset.



## TROUBLE SHOOTING

If the light doesn't turn on, remove battery, wipe both ends with a clean, dry cloth and reinstall battery. Check the battery to ensure that it is making secure contact with the terminals. If this doesn't work, replace with a new battery.

## APP HELP




## USO

El rango operacional entre su dispositivo Bluetooth y las luces es de 26.2 pies (8m). Las luces “Hijo” se puede instalar a una distancia de hasta 5 m de las luces “Padre”. La distancia depende del dispositivo Bluetooth y del ambiente. Abra la App y seleccione Ver tutorial para recibir instrucciones o seleccione Controlar mis luces para empezar a usar sus luces. La función temporizador no está disponible para este Las luces de camino. Para extender el tiempo de ejecución, el control de Bluetooth queda inactivo al pasar las 4 horas de uso. El control Bluetooth se reanuda cuando se cargue la batería al día siguiente. Para invalidar esta medida puede apagar y encender las luces. Esto reducirá el tiempo de ejecución hasta que el sol recargue las baterías de sus luces.



## TUTORIAL DE LA APP





## INSTALACIÓN

1. Antes de la instalación, descargue la App para asegurarse de que sea compatible con su teléfono. Descargue la **App Westinghouse Smart Landscape** de App Store o Google Play. También puede escanear los códigos QR que aparecen a continuación. Recuerde que la compatibilidad de la App solo corresponde a dispositivos iPhone (4ª generación o superior) o Android™ (5.0 o superior).



2. Asegúrese de tener habilitado Bluetooth en su dispositivo celular y de que esté descubrible. La forma de hacerlo dependerá de su dispositivo. Si necesita ayuda, visite el sitio web del fabricante.

3. Las luces de camino incluyen una luz "Padre" y una luz "Hijo". La luz con la etiqueta grande en la parte superior es la luz "padre". Esta luz también tiene un botón de reinicio ubicado debajo del panel solar. Solo la luz "padre" funciona independientemente. Con los paneles solares mirando hacia abajo, ubique cada luz sobre una superficie plana. Esto simulará la oscuridad. Primero hay que encender el interruptor de encendido de la luz "padre". Luego, encienda el interruptor de encendido de la luz "hijo". Puede llevar unos 15 a 30 segundos hasta que ambas luces se enciendan por igual.

4. Retirar el film protector de los paneles solares y las pegatinas de los productos.



### ENSAMBLADO (ALGUNAS PARTES PUEDEN VENIR PREARMADAS)

4. Alinee las pestañas de la (Parte B) con las ranuras dentro de la (Parte A) y gire la (Parte A) en la dirección de las manecillas del reloj hasta que las pestañas estén firmemente apretadas. Deslice la (Parte C) sobre la (Parte B). Separe la estaca (Parte D) de la parte inferior de la (Parte C) y dele la vuelta para que la punta quede hacia afuera y vuelva a insertarla a la parte inferior de la (Parte C). Presione la estaca entrando en la tierra hasta que el collar superior esté a nivel con la superficie del suelo.

**NOTA: Si el suelo está duro y apelmazado, humidézcalo con agua antes de introducir la estaca, con lo que evitará roturas.**

5. Instalar luz solar donde va a recibir luz directa sol durante al menos 8 horas cada día. Evite los lugares sombreados e instalar lejos de fuentes de luz durante la noche que prohibirán la luz funciona correctamente.


6. **PARA EL PRIMER USO:** la luz solar necesita cargarse bajo luz solar directa por un periodo de entre 8 y 12 horas con el interruptor en la posición "on" (prendido) para permitir que las baterías recargables alcancen su capacidad máxima.



## REPLACING THE BATTERY

Rotate (Part A) so that it releases from the ledges. Slide the power switch to the "OFF" position. Remove the screw from the battery cover using a Phillips head screwdriver. Pull up and remove battery cover. Remove the old battery and replace with a new 3.7V, 2000 mAh lithium (18650) rechargeable battery. Replace the battery cover removed earlier. Slide the power switch to the "ON" position. Replace shade by twisting clockwise until secure.

**For optimum performance, allow solar light to charge in direct sunlight.**





## SET DE LUCES LED SOLARES CONTROLADAS POR BLUETOOTH®

WARNING: Do not dispose of lithium batteries in municipal waste stream or by fire as batteries may explode. Do not open, short circuit, or mutilate batteries. Dispose of batteries in accordance with Local, State, and Federal regulations. Do not mix old and new batteries. Do not mix alkaline, standard (Carbon-Zinc), or rechargeable (Nickel Cadmium or Nickel Metal Hydride) batteries .

Ⓜ, WESTINGHOUSE, are trademarks of Westinghouse Electric Corporation. Used under license by Sky Rich Star Limited. All Rights Reserved.

iPhone is a registered trademark of Apple Inc. registered in the U.S. and other countries. Android is a trademark of Google Inc. Google Play and the Google Play logo are trademarks of Google Inc.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and use of such marks by Sky Rich Star Limited is under license. Other trademarks and trade names are those of their respective owners.


The **Westinghouse Smart Landscape App** may require periodic updates without prior notice. Check your mobile app store for the most updated version.

For assistance with assembly or instruction, parts and customer service, call:

U.S.A. & Canada only: 1-844-551-0680

8am – 5pm Monday – Friday, Central Standard Time Or email: [Customerservice@qx-usa.com](mailto:Customerservice@qx-usa.com)

[www.westinghousesolarlights.com](http://www.westinghousesolarlights.com)



Cambios o modificaciones no aprobados expresamente por la parte responsable del cumplimiento pueden anular la autoridad del usuario para poder operar este dispositivo.

### Manual de instrucciones

Modelo: SR15AA01H-78

## FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.