

FCC:

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference and 2) This device must accept any interference received, including interference that may cause undesired operation.


Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/TV technician for help.

Care and Maintenance:

- The supply terminals are not to be short-circuited.
- Batteries are to be inserted with the correct polarity.
- Do not dispose of batteries in a fire as batteries may leak or explode.
- Non-rechargeable batteries are not to be recharged.


4/AA Batteries Not Included. Insert battery as indicated on compartment. Do not mix old and new batteries. Do not mix alkaline, standard or rechargeable batteries. Remove and properly dispose of expired batteries. Do not allow children to play with or replace batteries.



RC TANK

Hobby Lobby Stores, Inc. • Oklahoma City, OK 73179 • www.hobbylobby.com

Thank you for choosing the Tank. This manual will provide you with basic directions for assembly, operation, and other important product and safety information. Please review the manual carefully before using this product. Store this manual in a safe place for future reference.



Battery Installation:

- 1) Firmly hold the pedestal in one hand and pull the controller up with the other hand. Remove antenna.
- 2) Counter clockwise, unscrew the vehicle from the pedestal. Remove the vehicle by sliding the Tank forward.
- 3) Unscrew the battery compartment and remove the cover. Insert 4 AA batteries, using the polarity markings in the compartment. Replace the battery compartment cover and screw shut.

Assembly:

- 1) Move the controller power switch to ON. The launch light will illuminate.
- 2) Screw antenna into the hole at the top of the controller.

Charging:

- 1) Slide side compartment door on controller open.
- 2) Remove charging plug and insert plug into charging jack on the bottom of the tank. The charging light will illuminate.
- 3) Once the charging light turns off, the Tank is fully charged. Remove plug and replace charging plug back inside of compartment.

To Operate:

- 1) Extend the antenna.
- 2) Move power switch on the bottom of the Tank to ON.
- 3) Place the Tank on the ground. When the function indicator lights up, the Tank is fully functional.
- 4) Use the Left and Right buttons to steer the Tank.
- 5) Use the Up and Down buttons to move the Tank forwards and backwards.

Note: If car begins to lose power, replace batteries.

Hobby Lobby Stores, Inc. • Oklahoma City, OK 73179 • www.hobbylobby.com