

blockbot


Instruction Book




LEVEL 01

LEVEL.01 Part List

OUR BLOCKS



NORMAL BOLCKS



Remote Control Instructions

Model: LB0006

CANCEL THE BLUETOOTH PAIRING BUTTONS


POWER SWITCH BUTTON

INDICATOR LIGHT

JOYSTICK

BLUETOOTH SWITCH BUTTON

A: ACCELERATOR KEY
 B: SLOW DOWN
 C: THE CAR SPINS A
 CIRCLE OF KEYS
 D: LED BUILDING
 BLOCKS LIGHT COLOR
 SWITCH KEYS



IMASTER SWITCH FUNCTION MODEL

Instructions:

1. The inside of the remote control needs to add 7# batteries.
2. Switch the main control function: each time you switch once the mode, the order of remote control, obstacle avoidance, straight line, ●●● after the flash into the various modes of light, remote control ●, obstruction is ●, straight ●.
3. Occurs button or rocker operation: 0.5 seconds flash once, remote control mode is ●, obstacle avoidance ●, straight line ●.
4. No operation Auto power off: 4 minutes without operation, automatic shutdown, light off ●.
5. The power is not enough automatic shutdown: the user is not enough to power, and shutdown, ●●● after flashing three times, shutdown ●.

Remote Control Instructions

TURN ON POWER




Press 1 second



After the connection is successful, ●●●, ● 0.5s flash, ● always bright
After the connection fails, ●●● after, ● 0.5s flash, ● 1s slow flash

START TO CONNECT



Press 1 seconds



After the connection is successful, ● 0.5s is flashing, ● light is on
After the connection fails, ● 0.5s flash, ● 1s slow flash

Remote Control Instructions

CANCEL THE CONNECT



Press 3 seconds



Cancel bluetooth pair: ●0.5 s flash, then, ●●●after a flash, it will turn into●●●a slow flash

TURN OFF THE POWER



Press 3 seconds



Turn off the handle power: the lights go out●

App Usage instructions

TURN ON THE CONNECTION

Turn on Bluetooth connection between building block and phone.



SCAN THE BLOCK

Click the scanning key to scan the building block equipment



App Usage instructions

SELECT THE BLOCK

Select the scanned blockbot device



READY TO GO

When everything is ready, let's play.




App Usage instructions

CHARGING



CHARGE MODULE




Please install the battery block to power the toy.



When charging a toy, you need an adult to accompany it.

The input voltage:5.0V
Input current:1000mA

Styling show



Styling show



WARNINGS

FCC STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

www.iblockbot.com