



Thank you for trusting MUVEACOUSTICS with delivering you excellence in sound. We encourage you to connect with us and become a part of our community!

**SCAN THE QR CODE YOU WILL FIND INSIDE. SHARE WITH US YOUR PRODUCT EXPERIENCE.**

## USER MANUAL AND WARRANTY

MA-3040



### JOIN THE COMMUNITY

SIGN UP to receive

- Special Offers!
- Access to Events!
- Contests!
- News on new products launched

[www.muveacoustics.com/community](http://www.muveacoustics.com/community)



### Bluetooth Connection

This product has Bluetooth wireless technology. It is compatible with Bluetooth wireless equipped computers, smartphones and MP3 players.

To use Bluetooth for you audio connection pair TAO with your audio source (music player, smartphone, laptop or other Bluetooth equipped device that can act as audio source). First of all, take out the TAO earbuds from the charging case for power on and go to pairing mode. Then the Bluetooth feature is enabled on your mobile device in order to search for available devices. In a few moments 'MUVEACOUSTICS:TAO' will appear on your list of possible Bluetooth connections. Press 'pair' or 'connect' on your device and when the connection is made, you can hear 'your device is connected'.

The period of Bluetooth pairing is about 90 seconds. If there is no pairing, TAO will shut off automatically after 10 minutes.

From now on, when you turn on TAO, it will automatically search for the last Bluetooth device it was paired with.

To pair with another device, you should shut off both earbuds and disable the Bluetooth connection of your device. Then turn on the earbuds and repeat pairing procedure for another device.

### MUVEACOUSTICS ONE-YEAR LIMITED WARRANTY

MUVEACOUSTICS TAO earbuds have been subjected to a thorough series of tests to ensure the highest level of dependability. It is unlikely that you will experience any problem, but if a defect should become apparent during the use of this product, MUVEACOUSTICS warrants to the original purchaser that this product will be free from defects in material and workmanship for a period of 12 months from the date of your original purchase from an authorized dealer. If a defect covered by this warranty occurs, MUVEACOUSTICS, at its option, will repair or replace the product purchase at no repair charge (postage charges will apply). If a replacement is necessary and your product is no longer available, a comparable product may be substituted at the sole discretion of MUVEACOUSTICS.

This warranty does not cover normal wear and tear, abusive use or misuse, modification, tampering or by any other cause not related to either materials or workmanship. This warranty does not apply to product used for any industrial, professional or commercial purposes.

### CUSTOMER SERVICE



For any service or technical queries, please contact our service team on the below email.



Email: [consumersupport@zeeva.com](mailto:consumersupport@zeeva.com)

Keep all relevant information for future reference

Imported and distributed by  
Zeeva Electronics Private Limited.  
All rights reserved.

901-902, Trade World C wing  
Kamla Mill Compound,  
Senapati Bapat Marg,  
Lower Parel West,  
Mumbai-400013



MuveAcoustics



muveacoustics\_



MuveAcoustics

### FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: 2ANVW-MA-3040  
1936032



### Warning And Cautions for the charging case and earbuds:

1. Do not fully submerge in water. The earbuds are IPX5 water resistance only.
2. Keep the earbuds and charging box clean and dry for storage and charging. Avoid dusty, damp, and dirty environments. Using the device in these environments may damage the circuitry.
3. Do not use the device during thunderstorms to avoid any lightning-related damage or injury.
4. Only charge or use the device at ambient temperatures between 0 deg °C/ 32 deg °F and 45 deg °C/ 113 deg °F.
5. Keep the device away from excessive heat sources and direct sunlight. Do not throw it into fire or in heating devices, such as microwave ovens, stoves or radiators. The device may even explode in extreme overheating circumstances.
6. Do not store device in enclosed vehicle.
7. Do not attempt to disassemble or remanufacture the device, insert foreign objects into it, or immerse or expose it to water or other liquids. Doing so may lead to fire, explosion or other hazards.
8. Do not attempt to burn the device as it may explode.
9. Dispose of the device in accordance with local regulations. Do not dispose of the device in normal household waste. Improper device disposal is dangerous and could cause an explosion. Please respect local laws on the disposal of electronic products and their accessories and support recycling efforts.
10. Keep the device out of reach of children and pets to prevent them from accidentally swallowing and choking on the small parts of the device. Biting or swallowing the device could lead to serious injury.
11. Do NOT allow small children to use the earbuds.
12. Do not drop, squeeze, or pierce the device. If excessive pressure is applied to the device, the device may short-circuit or overheat.
13. When the device is being charged, make sure the power source is close to the device and easy to reach.
14. When the device is fully charged, disconnect the charger from the device and unplug the charger from the power outlet. Do not leave charging overnight.
15. Do not use the charging case in excess of its output rating.
16. Use caution and follow applicable laws regarding mobile phone and headphones use if using the earbuds for phone calls while driving. Some jurisdictions impose specific limitations, such as single ear piece configuration, on the use of such products while driving. DON'T use the earbuds for any other purpose while driving.
17. Do not use a charging case that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury to persons.
18. Do NOT use the earbuds at a high volume for any extended period.
  - To avoid hearing damage, use your earbuds at a comfortable, moderate volume level.
  - Turn the volume down on your device before placing the earbuds in/on your ears, then turn the volume up gradually until you reach a comfortable listening level.
19. Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property and we cannot control the operating process during the time the user using this product.
20. In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.



RF warning statement:  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Before your first use, please insert the earbuds into the charging case and connect the micro USB cable provided to the charging case and to a USB power source. It takes about 2-2.5 hours for a full charge.

## Earbuds

### 1 Bluetooth Sync Indicator

White LED lights up during charging and it will turn off once fully charged.

### 2 Power / Multifunction Button (MFB)

#### For power on:

- When the earbuds are inside the charging case (being charged or fully charged): Take the earbuds from the charging case, both earbuds switch on automatically and you can hear "power on". Then, they will connect to each other automatically and you can hear "connecting".

Or

- When the earbuds are off (outside charging case): Press the MFB of both earbuds for 2 seconds to turn the earbuds on.

#### Pairing the earbuds with a Bluetooth device

- Take both earbuds out of the charging case and insert them into your ears. The distance between left and right earbud should not exceed 50 cm otherwise there may be problem in connecting each other.
- You will hear the voice prompt "power on", "connecting" and "pairing" from both left and right earbud. The earbuds are in pairing mode now. The LED of the right earbud is flashing in blue and white.
- Activate the Bluetooth feature of your Bluetooth device.
- Select the "MUVEACOUSTICS:TAO" from the list of found Bluetooth devices. If pairing was successful, you can hear the voice prompt "your device is connected" from right earbud. Then the LED of the earbud turns off.

If there is no connection is made within 90 seconds, pairing mode is terminated and the earbuds will turn to idle mode. Please turn off the earbuds and repeat the pairing procedure if necessary.

#### For power off:

- Place both earbuds into the charging case. They will turn off automatically and also be recharged.

Or

- You can also press and hold the MFB of any earbud for 4 seconds. Both earbuds will turn off and you hear "power off".

#### Play / Pause

Music playback pauses when you press the MFB of any earbud once and resumes when you press once again.

#### Volume Up

Double press the MFB button of the right earbud.

#### Next Song

Press and hold the MFB of the right earbud for 1 second and hear the tone notification.

#### Volume Down

Double press the MFB button of the left earbud.

#### Previous Song

Press and hold the MFB of the left earbud for 1 second and hear the tone notification.

#### Voice Assistant

Triple click the MFB of either left or right earbud to activate the voice assistant feature of your Bluetooth device. Voice assistant functions vary depending on your phone, tablet or application.

#### Receive a phone call

Press the MFB once of either left or right earbud.

#### End a phone call

Press the MFB once of either left or right earbud.

#### Refuse a phone call

Press and hold MFB for 2 seconds of either left or right earbud.

#### Reset earbuds to factory settings

When there is problem in connecting the earbuds to each other, turn off the earbuds, then press and hold the MFB simultaneously for 10 seconds. You can hear the voice notification of "reset". The earbuds are reset to the factory settings. All pairing information is deleted. Then put the earbuds in the charging case for next use.

## Charging Case \*

When the power of the earbuds is low, you can hear "battery low" every 2 minutes. Please re-charge them by placing them in the charging case otherwise they will turn off automatically after some minutes.

Charging case is also a storage for the earbuds.

- Use the micro USB cable provided with this device for connecting USB power source to the charging case in order to charge up the built-in battery of the charging case.
- The input voltage to the charging case is DC 5V and minimum 1A current capacity. In order to charge the device in safe manner and reliable conditions, please only adopt certified appropriate charger / adapter for charging.
- The white LED indicators are flashing while the charging case is being charged. All of them will be always on when the charging case has been fully charged.

### 3 Indication of power level of built-in battery of charging case

LED status	Power level of built-in battery	LED status	Power level of built-in battery
••••	0 - 25 %	•••••	50 - 75 %
•••••	25 - 50 %	•••••	75 - 99 %
•••••	100 %		

- White LED of both earbuds lights up during charging and it will turn off once fully charged.
- You can charge the earbuds as long as the charging case still has power, no matter the charging case is being charged or not.
- You must charge the charging case and earbuds if they have not been used for more than 6 months.
- When the charging case is not being charged and you want to check the power level of it, please take out the right earbud from the charging case or put the right earbud back into the charging case. The LED indicators of the charging case show the power level of the built-in battery for 3 seconds.

## Operational Guidance

Function	Button
Play / pause	Press MFB on either one of the earbuds once
Increase volume	Press MFB of the right earbud twice
Decrease volume	Press MFB of the left earbud twice
Previous song	Press and hold MFB of the left earbud for 1 second, with tone notification
Next song	Press and hold MFB of the right earbud for 1 second, with tone notification
Answer / end a call	Press MFB on either one of the earbuds once
Refuse incoming call	Press and hold MFB on either one of the earbuds for 2 seconds
Voice assistance **	Triple click MFB on either one of the earbuds

### \* Please Note:

- TAO earbuds come with a lithium-ion polymer battery. For best results, fully charge TAO earbuds before use. It will take 2 - 2.5 hours to fully charged.  
Place the earbuds in the charging case before you start charging.  
To charge, plug the micro USB cable into charging case and plug the standard USB connector into your DC5V USB power source.  
You can also charge the earbuds as long as the charging case still has power (without connecting to USB power source).  
The charging case can be charged up individually and can be used for charging the earbuds later.
- Voice assistant functions vary depending on your phone, tablet or application.
- TAO earbuds is rated at IPX5 waterproof and true wireless.
- Charging case is not a waterproof device.