

OUICK TIPS:

- Double check your alignment be sure to center the device on the charging surface to ensure the most efficient and fastest charge times.
- Certain materials and thicker phone cases can interfere with wireless charging.
- Not all devices are compatible with wireless charging, please check the devices user manual for compatibility information.
- This is a high speed 3-in-1 charger, please use the USB-C cable and power delivery wall plug that was included; using different items may cause slower charging.

WHATS INCLUDED:

- 3-IN-1 Wireless Charger
- USB-C to USB-C Charging Cable
- · Power Delivery Wall Plug

LED INDICATOR GUIDE:

0 Solid White - Charging your device / Fully charged

#Flashing White - Foreign object detection, metal or other materials that may cause overheating and damage the charger, or the device your charging, remove them immediately

HOW TO CHARGE:

- Place the charger on a flat sturdy surface
- Plug the wall plug into an outlet, and the USB-C cable into both the wall plug and 3-in-1 charger. If you need to use a different power source be sure it is a USB power supply of DC9V 3A minimum. warning: please use a UL compliant power supply.
- Place your device on the correct charging surface making sure the device is centered on the charging surface or the device will not charge.

note: The phone charging stand will charge all Qi-enabled devices. Remove anything with a magnetic strip, like credit cards, to prevent damage before charging.

- The phone charging stand allows for wireless charging up to 10W; the watch charging stand and earbud case charger allow for wireless charging up to 5W.
- Remove the phone from the phone charging stand before changing the orientation of the phone.
- Charge time will vary by device.

TROUBLESHOOTING:

- Double check the connections between the USB-C cable and wall plug, ensuring they are fully plugged in.
- Some phone cases may cause interference with wireless charging; remove the case for best
- Make sure the device is centered on the wireless charger.
- Wireless charging is compatible with newer devices as well as other Qi-enabled devices; consult your devices user guide to ensure compatibility.
- When using the earbud case charging base the device may still charge even when not fully centered, if the indicator light is white the device is being charged.
- If the indicator light flashes white while switching the phone orientation on the phone charging stand, remove the phone and recenter it in the preferred position.
- Having trouble with your device? Be sure you're running the latest software on your devices. You can do this by doing a 'software update' in the settings of your device.

SAFETY:

- Do not modify or repair this device.
- Do not use in high temperatures or extreme weather.
- Do not use chemical detergents to clean your device, use a soft dry cloth.
- Immediately unplug it from its power source if it gets wet.
- Keep the charger away from heat and direct sunlight.
- Remove credit cards and other cards with magnetic strips to prevent damage to the cards.

SAVE THESE INSTRUCTIONS

FCC ID: 2AO23-PMWCW09 Model: MWCW09 Input: 9.0V=3.0A / 12.0V=2.5A Phone Charging Stand Output: 10W Max Watch Charging Stand or Earbud Case Charging Base Output: 5W (for each) Max Made in Vietnam

This device compiles with part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications to this unit not express approved by the party responsible for compliance could viol drule user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are design provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, installed and used in accordance with the instructions, may cause harmful interference to radio communications.

er, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or telean be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following me

- Reorient or relocate the receiving antenna.

 Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

 Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with m distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

8725 COLUMBINE RD EDEN PRAIRIE, MN 55344-6695, PO Box # 44895 Distributed by ZSOU.