


FRONT


Qi Wireless Charger Instructions

TOP



light indicators

BACK



Charge Port

Compatible With:

• iPhone XR	• Galaxy S9+
• iPhone XS Max	• Galaxy S8
• iPhone XS	• Galaxy S7
• iPhone X	• Moto Z
• iPhone 8 Plus	• LG G6
• iPhone 8	
• Galaxy S9	

Before You Begin:

- Centering the device on the charging surface ensures the fastest and most efficient charge.
- Remove credit cards or other cards with magnetic strips to prevent damage to the cards.
- Certain phone cases can interfere with the ability to charge the device.

Charging:

- Place the charger on a flat surface.
- Plug in the micro-USB cable provided to a DC 5V power source.
- Place your device onto the center of the wireless charger.

Indicators:

- Solid White - Ready to charge your device
- Solid Blue - Charging your device
- Flashing White - Foreign object detection, pieces of metal or other materials may cause overheating and damage your charger or phone. Remove them immediately.

Wireless Charging Pad
model: IH-Q11019R more on the back →



BACK

Troubleshooting:

- Double check that the micro-USB cable is plugged in and DC 5V power source is working.
- Certain phone cases may interfere with wireless charging. Remove the phone case for best results.
- Double check the device is centered on the wireless charger.

Safety:

- Keep the charger away from heat and direct sunlight.
- Do not modify or repair this device.
- Do not use in high temperatures or extreme weather.
- Use a soft dry cloth to clean your wireless charger.
- Immediately unplug the device from the power source if it gets wet

SHUTTERFLY  

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

CAUTION: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

9.5 cm

9.5 cm

L95*W95mm说明书,材质:80g书写纸,双面黑色印刷,符合RoHS.(C16-9)