

---

# Manual

**Thanks for choosing and using our multi-functional smart wireless charging mount.**

**Please carefully read the instruction manual and precautions before use.**

## • Mount Devices

---



## • product function-instruction

---

1. Automatic induction gesture recognition, no need to manually switch the phone holder , Easy to operate by one hand;
2. Built-in wireless charging transmitter module for mobile phone to do wireless charging;
3. Equipped with USB charging port;

## • Product function parameters

---

1. Input : DC 4.5V---DC5.2V/2~3.5A
2. Output:5V/1A(MAX)
3. Operating temperature: -10 to 60 degrees
4. Charging power: 5W
5. Charging efficiency: 60% to 75%
6. Charging distance: 0.5-6.0mm
7. Standby power consumption: the average power consumption of the whole machine is less than 60mW
8. Over temperature protection: when charging, the temperature is higher than 60 degrees, automatically stop charging, transmitter light flashing red (one second on / one second off), when the temperature drops to 55 degrees, will automatically recharge
9. Over current protection: when charging, the input current is greater than 2A, automatically stop charging, the transmitter light flashing red (0.5 seconds /0.5 seconds off), to prevent damage to charger

## • Product function parameters

---

10. Over voltage protection: when charging , the input voltage is greater than 6V, automatically stops charging, the transmitter light flashes red and green (0.1 seconds on / 0.1 seconds off), to prevent damage to the charger
11. Executive standard: implement Qi wireless charging standard
12. Charging indicator: Charging flashing blue light; fault flashing red light ; standby flashing breathing light; the input power is too high, red and blue lights fast flash (0.1 seconds on /0.1 seconds off)
13. Support WPC (5W) Qi wireless charging protocol

## • Product use guide

---

1. When using this product, please confirm that the product is connected to the power.
2. When the USB connection is successful, the two-color LED lamp flashes 4 times (green, red, red green, green) and then goes out;
3. When the mount is in standby mode, LED is a green breathing effect, and when the phone is charged or full of electricity, it is green. The red light flashes and is not allowed to charge when errors such as excessive temperature, flow, and foreign bodies are wrong. When trouble occurs, insert the charging line into the USB. Use the 5V/2.5A~3.5A standard charger.
4. When the handset needs to be clamped, please move the mobile phone to the 50~80mm above the mount. The mount automatically opens the clip, and easily puts the mobile phone into the mount. The clip automatically retracts the handset. If you need to take your handset, touch the on-off keying on left side of the mount , The clip is opened automatically and handset can be taken out.

## • Product use guide

---

5. In order to increase the user experience and interaction, there are two kinds of stay time for the holder expansion ear clip. According to the size of the cell phone, long press the side key (5 seconds), ear clip retractable longer residence time . To shorten the time, long press 5 seconds .
6. This product is equipped with a wireless charging (Qi standard) receiver, and if the handset does not have wireless receive function, please buy Android or apple wireless receiver to use together.

## • Precautions

---

Please carefully handle your charger and accessories, the following recommendations will help you effectively use the warranty service.

- Please keep the equipment dry. Rain, moisture and various water may contain minerals that will corrode the circuit. If the equipment is wet, please dry the product as soon as possible or use a clean soft cloth to wipe.
- When charging, please select the regular production 5V/2.5~3.5A charger. Improper use of charger or incompatible charger may present risk of unstable function, fire and other dangers. Do not use damaged charger.
- Please do not attempt to charge the battery exposed equipment or battery case broken, and do not charge the equipment which is not compatible with this product.
- Do not store the equipment in a cold place. Otherwise, when the equipment temperature rises to normal temperature, moisture will be formed inside it and damage the electric appliance.

## • Precautions

---

- Do not attempt to open the equipment, unauthorized disassembly or modification will damage equipment and wireless charging equipment related regulations.
- Do not throw, tap or shock the equipment; rough handling of the equipment will damage the internal circuit board and the mechanical structure.
- Use the clean and moist soft cloth to clean the surface of the equipment. Do not use or store the equipment in dusty or dirty places.
- Some components of this product are magnetic and metal materials may be adsorbed onto this product. Please do not use bank cards, credit cards or other items with magnetic media near the product so as to avoid losing its stored data due to degaussing.

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.