

Mobile Phone Quick Guide

Instructions.









Thank you for purchasing this product. For your cellular phone to work properly, please follow the instructions in the manual. To prevent any possible incidents or malfunction, please follow all safety warnings. If the function upgrade described in the manual content does not agree with your actual products, please refer to our company subsequent release of information.











Contents

| | |
|--|------------------|
| For Your Safety | 4 |
| General Safety | 4 |
| Product Handling | 5 |
| General Statement on Handling and Use | 5 |
| Electrostatic Discharge (ESD) | 7 |
| Antenna | 7 |
| Normal Use Position | 7 |
| Phone Heating | 7 |
| Getting Started | 8 |
| Overview | 8 |
| Keys Explained | 9 |
| Install the SIM card / SD card | 10 |
| Charging the Battery | 10 |
| Switching Your Phone On/Off | 11 |
| Waking Up Your Phone | 11 |
| Getting Around Your Phone | 11 |
| Home Screen | 错误！未定义书签。 |
| Use the phone as a USB memory | 12 |
| Turning On Wi-Fi | 12 |
| Turning On Data Services | 12 |
| HAC warning | 13 |
| IEEE1725 WARNING | 15 |

For Your Safety

General Safety

| | | | |
|---|---|--|--|
|  | Don't make or receive handheld calls while driving. And never text while driving. |  | Don't use at petrol stations. |
|  | Keep your phone at least 10 mm away from your ear or body while making calls. |  | Your phone may produce a bright or flashing light. |
|  | Do not leave your phone and its accessories within the reach of small children or allow them to play with it. Small parts may cause a choking. |  | Don't dispose of your phone in fire. |
|  | Your phone can produce a loud sound. |  | Avoid contacting with anything magnetic. |

| | | | |
|--|--|---|---|
|  | <p>Keep away from pacemakers and other electronic medical devices.</p> |  | <p>The phone's normal operating temperature is 0°C ~ 50°C .In order to ensure the normal phone functions, do not use this phone outside the temperature range</p> |
|  | <p>Switch off when asked to in hospitals and medical facilities.</p> |  | <p>Avoid contacting with liquids. Keep your phone dry.</p> |
|  | <p>Switch off when told to in aircrafts and airports.</p> |  | <p>Don't take your phone apart.</p> |
|  | <p>Switch off when near explosive materials or liquids.</p> |  | <p>Only use approved accessories.</p> |
|  | <p>Don't rely on your phone for emergency communications.</p> |  | <p>To prevent possible hearing damage, do not listen at high volume levels for long periods.</p> |

Product Handling

General Statement on Handling and Use

You alone are responsible for how you use your phone and any consequences of its use.

You must always switch off your phone wherever the use of a phone is prohibited. Use of your phone is subject to safety measures designed to protect users and their environment.

- Always treat your phone and its accessories with care and keep it in a clean and dust-free place.
- Do not expose your phone or its accessories to open flames or lit tobacco products.
- Do not expose your phone or its accessories to liquid, moisture or high humidity.
- Do not drop, throw or try to bend your phone or its accessories.
- Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
- Do not paint your phone or its accessories.
- Do not attempt to disassemble your phone or its accessories, only authorized personnel can do so.
- Please check local regulations for disposal of electronic products.
- Do not carry your phone in your back pocket as it could break when you sit down.
- Use careful with the earphone maybe possible excessive sound pressure from earphones and headphones can cause hearing loss.
- **Adapter** : adapter shall be installed near the equipment and shall be easily accessible.

- **CAUTION** : RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Electrostatic Discharge (ESD)

Do not touch the SIM card's metal connectors.

Antenna

Do not touch the antenna unnecessarily.

Normal Use Position


When placing or receiving a phone call, hold your phone to your ear, with the bottom towards your mouth.

Phone Heating

Your phone may become warm during charging and during normal use.

Getting Started

Overview



- 1、 Camera
- 3、 Charging port
- 5、 Camera key
- 7、 Down volume key
- 9、 Receiver
- 11、 Messages key
- 13、 Right menu key

- 2、 Headset port
- 4、 Microphone
- 6、 Up volume key
- 8、 Speaker
- 10、 Left menu key
- 12、 Call key
- 14、 Navigation key

Keys Explained

| Key | Function |
|----------------|---|
| Power/End Key | <ul style="list-style-type: none">• Long pressing the Power/End key to power on/off.• Press to go to the Home screen.• To end the call, press the Power/End key |
| Navigation Key | <ul style="list-style-type: none">• Press CENTER soft key to go to All app list from Home screen.• Press UP/DOWN/LEFT/RIGHT to navigate to any options or menus for the current screen. |
| Menu Key | Press to get the options for the current screen. |
| Back/Clear Key | Press to go to the previous screen. |
| Volume Keys | Press or hold to turn the volume up or down. |
| Call Key | <ul style="list-style-type: none">• When a call comes, press the Call key to receive the incoming call• Enter the desired number then press the Call key to place the call• From the Home screen, press the Call key to access Call log |

| Key | Function |
|--------------|---|
| Messages Key | Press the Messages key to enter the SMS screen |
| Camera Key | Press the Camera key to enter the camera screen |

Install the SIM card / SD card

1. Ensure that the phone is off, then take the battery out of the device.
2. Insert the Nano-SIM card and the Micro SD card as instructed on the card

Charging the Battery

When you first get your new phone you'll need to charge the battery.

1. Connect the charger to a standard AC wall outlet.
2. Disconnect the charger when the battery is fully charged.

Switching Your Phone On/Off

Make sure the SIM card is in your device and the battery is charged.

- Hold **Power Key** to switch on your phone.
To switch it off, hold **Power Key** to get the phone power off.

Waking Up Your Phone

1. Flip the lid open to activate the screen display.
2. Press any key to wake the screen when the Phone goes to sleep with lid opened.

NOTE: If you have set an unlock password for your phone, you'll need to enter the password to unlock your screen.

Getting Around Your Phone

Choosing Your Wallpaper

1. Press **CENTER** soft key to **All Apps list** > navigate to **Settings > Personalization > Display > Wallpaper**.
2. Select **Wallpaper** from the **Select From** list, choose the image you want to use as the wallpaper, then press menu key to save.

3. You can also select **Gallery** or **Camera** from the **Select From** list to set new wallpapers.

Use the phone as a USB memory

1. Connect the phone and computer with the USB cable.
2. Press **CENTER soft key to All Apps list** > navigate to **Settings > Storage > USB Storage**, then select **Enabled**.

Turning On Wi-Fi

Press **CENTER soft key to All Apps list** > navigate to **Settings > Wi-Fi**, then select **ON**.

Turning On Data Services

Press **CENTER soft key to All Apps list** > navigate to **Settings > Mobile network & Data > Data connection**, then select **ON**.

HAC warning

US Information Concerning the Federal Communications Commission (“FCC”) Requirements for Hearing Aid Compatibility with Wireless Devices When wireless devices are used near hearing devices (such as hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference, and wireless devices also vary in the amount of interference that they generate.

The wireless telephone industry has developed ratings to assist hearing device users in finding wireless devices that may be compatible with their hearing devices. Not all wireless devices have been rated. Wireless devices

that are rated will have the rating displayed on the box together with other relevant approval markings. The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device is vulnerable to interference, you may not be able to use a rated wireless device successfully.

Consulting with your hearing health professional and testing the wireless device with your hearing device is the best way to evaluate it for your personal needs. This smartphone has been tested and rated for use with hearing aids for some of the wireless technologies that the smartphone uses. However, other wireless technologies may be used in this smartphone that have not been tested for use with hearing aids. It is important to try the different features of your smartphone thoroughly and in different locations to determine if you hear any interfering noise when using this smartphone with your hearing aid or cochlear implant. Consult your wireless service provider about its return and exchange policies, and for information about hearing aid compatibility.

Hearing aid compatibility rating for this smartphone: M4/T4.

How the ratings work

M-Ratings: Wireless devices rated M3 or M4 meet FCC requirements and are likely to

generate less interference to hearing devices than wireless devices that are not labeled. M4 is the better or higher of the two ratings.

T-Ratings: Wireless devices rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated wireless devices. T4 is the better or higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from wireless devices. For more information about the actions that the FCC has taken with regard to hearing aid compatibility with wireless devices and other steps that the FCC has taken to ensure that individuals with disabilities have access to telecommunications services, visit www.fcc.gov/cgb/dro.

a) Section 20.19(f)(1): an explanation of the ANSI C63.19 rating system.

b) Section 20.91(f)(3): disclosure statement for HAC-rated handsets operating over the GSM air interface in the 1900 MHz band with a user-selectable mode or a special mode necessary to meet the hearing aid compatibility standard for reducing the power under the provisions of Section 20.19(c)(1).

IEEE1725 WARNING

- a) Do not disassemble or open crush, bend or deform, puncture or shred
- b) Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- c) Only use the battery for the system for which it is specified
- d) Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- e) Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- f) Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard. Only authorized service providers shall replace battery. (If the battery is non-user

replaceable).

g) Promptly dispose of used batteries in accordance with local regulations

h) Battery usage by children should be supervised.

j) Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.

k) Improper battery use may result in a fire, explosion or other hazard.

Exposure to radio frequency signals

The smart phone radio is a low-power radio transmitter and receiver. It is designed to comply with the following:

- Federal Communications Commission (FCC) guidelines and limits
- Other relevant international guidelines regarding safety levels of radio frequency exposure for wireless devices

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules and Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference

(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body.

The highest SAR value :Head **0.63** W/kg ;Body-worn **1.07** W/kg

The National Council on Radiation Protection and Measurements (NCRP)10

To maintain compliance with radio frequency exposure guidelines and limits, keep the smartphone at least 15 mm away from your body. When you carry the smartphone on your body, use only accessories equipped with an integrated belt clip that are supplied or approved by the manufacturer. If you use a body-worn accessory not supplied by the manufacturer, verify that the accessory does not contain metal and keep the smartphone at least 15mm from your body.