


## CANDY LAMP USER MANUAL

### FOREWORD



Remove the product carefully from its packaging. Check that the product is not damaged and that it works correctly.

Do not attempt to make any repairs or carry out any modifications yourself, as this would invalidate

the guarantee.

If the product is damaged, or if you have any questions about using the product, please contact your retailer.

### FUNCTIONS:

#### Consecutive short clicks:

Please press button below the lamp to change color or mode.

**1: ON / White (3000°K)**

**2: Green**

**3: Red**

**4: Blue**

**5: Yellow**

**6: Pink**

**7: Deep Blue**

**8: Orange flame**

**9: Blue flame**

**10: Purple**



Lamp can be switched OFF with press 2 seconds

### BLUETOOTH

To control your Candy lamps using the Slide APP, please download the Slide APP from Google Play store or Apple APP Store.

Reset of the lamps is done through long press of the button (5 seconds push then release). The lamp flashes in different RGB colors. Please reset the lamps every time you use a new device to connect the lamps.

### CHARGING

Use the DC 5V3A power adapter included in the pack to recharge the lamp. Continuous red light when charging. A blue light indicates that the lamp is fully recharged.

### MAINTENANCE

Use a soft cloth and lukewarm water. Never use chemical cleaning agents! For very ingrained dirt use a neutral pH soap.

### TECHNICAL INFORMATION

Power supply: DC 5V 3A

2W

3.7V 2600mAh X2

Recommended operating temperature: 0 to 40 °C  
IP44  
7 hours autonomy  
6 hours charging time

## **REGULATORY COMPLIANCE**

The light source contained in this light is not replaceable; when it reaches the end of its life, the entire light must be replaced.

In accordance with WEEE Directive 2002/96/EC, you must return this product to a collection point for recycling at the end of its service life. If you require any further information, please contact Slide Design.

### **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.