

NEBULA

For FAQs and more information, please visit:

www.SeeNebula.com

✉ support@SeeNebula.com

☎ +1(800) 988 7973 (US) Mon-Fri 9:00 am - 5:00 pm (PT)

This manual is suitable for D0114111,D0114211,D0114311

1.SKU:D0114111

Plug : US Plug

Power :20W/50Hz Voltage :110V

2.SKU:D0114211

Plug : UK Plug

Power :40W/50Hz Voltage :220V

3.SKU:D0114311

Plug : EU Plug

Power :40W/50Hz Voltage :220V

Remote control information

Model:D0 115

RF Frequency:433.92MHZ

TX Power :10mw KVA:10mA

Battery :23A 12V *1pcs

FCC ID:2AOKB-D0115

© Anker Innovations Limited. All rights reserved.
NEBULA and the NEBULA logo are trademarks of
Anker Innovations Limited, registered in the
United States and other countries.

Model: D0114

51005002659 V01

Notice

Declaration of Conformity

 This product complies with the radio interference requirements of the European Community.

Hereby, Anker Innovations Limited. declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. For the Declaration of Conformity, visit the Web site
Motorized projector Screen

RF exposure information: The Maximum Permissible Exposure (MPE) level has been calculated based on a distance of d=20 cm between the device and the human body. To maintain compliance with RF exposure requirement, use the product that maintains a 20cm distance between the device and human body.

433MHz Frequency Range:433.92MHz;433MHz
Max Output Power:10 dBm(EIRP)

	AT	BE	BG	HR	CY	CZ	DK
	EE	FI	FR	DE	EL	HU	IE
	IT	LV	LT	LU	MT	NL	PL
	PT	RO	SK	SI	ES	SE	UK



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health, and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

Anker Innovations Deutschland GmbH
Georg-Muche-Strasse 3, 80807 Munich, Germany

Anker Technology (UK) Ltd I Suite B, Fairgate House, 205 Kings Road, Tyseley, Birmingham, B11 2AA, United Kingdom



This product complies with the radio interference requirements of the United Kingdom

Declaration of Conformity

Hereby, Anker Innovations Limited declares that the product type D0114 is in compliance with Radio Equipment Regulations 2017. The full text of the UK declaration of conformity is available at the following internet address: <https://uk.seenebula.com/>

FCC Notice

This device complies with the FCC rules, Part 15. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

The following importer is the responsible party.
Company Name: Fantasia Trading LLC
Address: 5350 Ontario Mills Pkwy, Suite 100, Ontario, CA 91764
Telephone:1-800-988-7973

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

Company Name: Fantasia Trading LLC
Address: 5350 Ontario Mills Pkwy, Suite 100, Ontario, CA 91764

Anker Innovations Limited
Room 1318-19, Hollywood Plaza, 610 Nathan Road, Mongkok, Kowloon, Hong Kong

NEBULA

by Anker



Motorized projector Screen Quick Start Guide

Important Safety Instructions

Read and understand all instructions before you use this device. Do not make any changes or settings that are not described in this manual. If physical injury, loss of data, or damage is caused by failure to follow instructions, the warranty does not apply.

1. Make sure the ceiling or wall can bear the load of the screen.
2. Do not place the screen near the devices with signal sources or fluorescent lamps, as these can interfere with the projected image. The beam will cause misoperation.
3. Do not expose the screen to fire as it is not fireproof.
4. Power off the device before removing the power supply from the socket.
5. Unplug the device if there are lightning storms or when unused for a long period of time.
6. Because a dirty or scratched projection screen will hurt the projection effect, please note the following:


- Do not touch the screen with hands.
- Do not write or draw on the screen.
- Do not scratch the screen using your nails or sharp objects.
- Do not clean the screen with corrosive chemicals including diluent.
- Put the screen away after use.

7. Improper installation of the screen may result in injuries or damage to the device. Nebula will not be held responsible for any loss, incidental, or consequential damage.

8. Clean the screen regularly.

1

Accessories



Mounting Motorized projector Screen

The Motorized projector Screen can be mounted on the wall or ceiling. Before mounting the screen, make sure you avoid placing the screen in direct light.


To mount the screen:

1. Draw a level line on the wall to mark the position for mounting the screen.
2. Drill a hole into the wall at each marking.
3. Mount the mounting plate (not provided) using the anchors and screws. Anchors are not needed for wooden walls. Make sure these two mounting plates are mounted at the same level, or the screen will skew to one side.
4. Hang the screen from the hook on the mounting plate.

2

Using Motorized projector Screen


1. Draw a level line on the wall to mark the position for mounting the screen.



⚠ Attention : Please note the voltage of the screen, then connect the correct voltage power.

3

2. Let the projector screen be energized, there will be a buzzer sound to show that the screen has been energized.



3. Use the remote control or switch on the screen to control the screen.

- To raise the screen, press the "Up" button;
- To lower the screen, press the "Down" button;
- Press the "Pause" button to fix the screen in its current position.

4. Power off the screen when it is not in use.

Note:

- Before rolling the screen, check the screen carefully and make sure there is no dust or foreign objects which may damage the screen.
- DO NOT roll up and down the screen continuously each time. Let the device that powers the screen cool down before use.
- Make sure there is enough space to fully open the whole screen.

4