



# NEBULA




## D0421 Nebula Gamepad User Manual

### What is Included



### Overview




### LED Indication

Status	LED indicator
Power on	Flashing green
Pairing	Android: flashing green iOS: flashing white Windows-based: flashing orange
Connected	Android: solid green iOS: solid white Windows-based: solid orange
Charging	Flashing red
Fully charged	Off


01

### Getting Started

- Before using for the first time, charge the gamepad with the included charging cable.
  - The LED indicator will flash red. Once fully charged, the LED indicator will turn off.



- Press and hold the HOME button for 3 seconds to power on.
  - The LED indicator will flash green.




02

### Pair and Connect to Nebula Capsule II

- Open the flip-up device holder and press and hold the Android button. The LED indicator will flash green.
- To pair your gamepad with Nebula Capsule II, select one of following options.

Option A: Insert the provided 2.4G nano receiver into Nebula Capsule II's USB port.



Option B:

- In Nebula Capsule II's **[Settings] > [Remotes & Accessories]** menu, select **Add accessories**.

The projector will begin searching for accessories.

04

# NEBULA

For FAQs and more information, please visit:

[www.SeeNebula.com](http://www.SeeNebula.com)

✉ support@SeeNebula.com


☎ +1 (800) 988 7973 (US) Mon-Fri 9:00 - 17:00 (PT)

©Anker Innovations Limited. All rights reserved. NEBULA and the NEBULA logo are trademarks of Anker Innovations Limited, registered in the United States and other countries. All other trademarks are the property of their respective owners.

Model: D0421

51005001449 V01

② Press the Android button to enter Bluetooth pairing mode. Once connected, the Android LED indicator will turn solid green.



You only need to pair the gamepad with Nebula Capsule II once. Once paired, the gamepad will automatically reconnect to your projector, and the LED indicator will turn steady.

### Using the Gamepad

1. Download a game from the Google Play store on the Nebula Capsule II's Android TV™ interface.




05

2. Play the game by using navigation buttons. Button configurations are different for each game; read each game's instructions before playing.



3. Press and hold the HOME button to turn off the gamepad.




Due to continuous app updates and changes, some games may not work properly with this gamepad. For iPhone/iPad, the gamepad is designed to be used with iCade-compatible games only. Please search online for an updated list of these games.

06

### Specifications

Charging voltage: 3.7V-5.2V  
Charging current: 1A-2A  
Operating humidity: 20%-80%  
Connection type: Bluetooth / 2.4G WiFi  
Charging time: 2-3 hours  
Maximum operating distance: Approx. 23 ft / 7m  
Battery capacity: 600 mAh  
Net weight: 7.3 oz / 206 g

### Notice

 This product complies with the radio interference requirements of the European Community.

### Declaration of Conformity


Hereby, Anker Innovations Limited declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. For the declaration of conformity, visit : [www.seenebula.com](http://www.seenebula.com).


This product can be used across EU member states.  
BT Operating Frequency Range: 2402-2480 MHz; BT Max Output Power: 2dBm

07

The following importer is the responsible party (contact for EU matters only)

Importer: Anker Technology (UK) Ltd  
Importer Address: Suite B, Fairgate House, 205 Kings Road, Tyseley, Birmingham, B11 2AA, United Kingdom

 Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

 This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

### FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is

no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.

### FCC Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure condition.

### Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

FCC ID:2AOKB-D0421

The following importer is the responsible party.

Company Name: Fantasia Trading LLC  
Address: 9155 Archibald Ave, Suite 202, Rancho Cucamonga, CA 91730, USA  
Telephone:1-909-484-1530

Anker Innovations Limited  
Room 1318-19, Hollywood Plaza, 610 Nathan Road, Mongkok, Kowloon, Hong Kong

09