
CUFYSECURITY

QUICK START GUIDE

EufyCam 2 WIRE-FREE HD SECURITY CAMERA SET





Anker Innovations Limited. All rights reserved. eufy Security and eufy Security Logo are trademarks of Anker Innovations Limited, registered in the United States and other countries. All other trademarks are the property of their respective owners.

51005002585 V01

TABLE OF CONTENTS

What's Included 02

Product Overview 03

Adding eufyCam 2 04

Mounting the Camera 05

Charging eufyCam 2

Notice

| / WHAT'S | INCLUDED

For eufyCam 2 installation



eufyCam 2 (T8114S)



Mounting Bracket



Indoor Mount



Micro-USB Charging Cable




Mounting Screws and Anchors




Hook (for Indoor Mount)

$2/\mathop{\mathsf{PRODUCT}}_{\mathsf{OVERVIEW}}$

eufyCam 2



- I. Photosensitive sensor
- 2. Camera lens
- 3. Motion sensor
- 4. Microphone 5. LED indicator



- 6. Sync button
- 7. USB charging port 8. Screw hole

02 EN **EN** 03

3/ADDING EUFYCAM 2

Adding eufyCam 2 to Your Existing System

On Eufy Security app, follow the onscreen instructions to add your eufy devices. Choose Add Device, then select eufyCam 2 to add it to your system.



4/MOUNTING THE CAMERA

Find a Good Mounting Spot

To find a spot to mount eufyCam 2, you need to test wireless signal strength.


- ① Open the Eufy Security app, go to Camera Settings > Mounting Guide.
- ② To test the wireless signal strength, take your camera and phone to the location where you want to mount the camera.
- ③ Move the camera as close to the HomeBase 2 as possible if the wireless.



04 EN EN 05

Select Height and Location


Hang eufyCam 2 7-10 ft (2-3 m) above the ground. This height maximizes the detection range of the motion sensor of eufyCam 2. Avoid placing eufyCam 2 under direct sunlight.




Mount the camera

The camera can be mounted both indoors and outdoors.


1. Turn the knob of the mounting bracket clockwise to loosen and disassemble it.



 Drill holes with a 15/64 inch (5.95mm) drill bit, then insert the anchors into the holes; anchors are necessary for walls that are made out of hard materials such as concrete, brick, or stucco.




Firmly screw the base of the mounting bracket onto the wall. Fasten the ball knob of the bracket to the base of the bracket.



06 **EN** 07

 Tighten eufyCam 2 to the mounting bracket and adjust the viewing angle by checking the live stream feed in the Eufy Security app.




Tips:

For troubleshooting, check Help on the Eufy Security App. Refer to App page for LED indicator status.


Mount the Camera Indoors

Stick the camera directly to any flat surface made out of iron. Or you can use the indoor mount to mount the camera:

Drill a hole. Use the included anchor if it's drywall and fasten the hook.



2. Hang the indoor mount on the hook.



3. Attach eufyCam 2 to the indoor mount and adjust the viewing angle.




08 EN EN 09


5/ CHARGING EUFYCAM 2

Charge eufyCam 2

Method I



Method 2



LED indication	Charging: Steady blue
	Fully charged: Off
Charging time	12 hours

6/ NOTICE

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an

IO EN EN II

experienced radio/TV technician for help.

FCC Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure condition. The min separation distance is 20 cm.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

The following importer is the responsible party. Company Name: POWER MOBILE LIFE, LLC. Address: 10900 N E 8th St , Ste 501, Bellevue WA 98004

Telephone: I-800-988-7973



C This product complies with the radio interference requirements of the European Community.

Declaration of Conformity

Hereby, Anker Innovations Limited declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. For the declaration of conformity, visit the Web site https://uk.eufylife. com/

Do not use the Device in the environment at too high or too low temperature, never expose the Device under strong sunshine or too wet environment.

The suitable temperature for eufyCam 2 and accessories is -20°C-50°C.

When charging, please place the device in an environment that has a normal room temperature and good ventilation.

It is recommended to charge the device in an 12 EN

environment with a temperature that ranges from

RF exposure information: The Maximum Permissible Exposure (MPE) level has been calculated based on a distance of d=20 cm between the device and the human body. To maintain compliance with RF exposure requirement, use product that maintain a 20cm distance between the device and human body.

CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Wi-Fi Operating Frequency Range: 2412~2472MHz: Wi-Fi Max Output Power: 18.88 dBm Anker Innovations Deutschland GmbH | Georg-Muche-Strasse 3, 80807 Munich, Germany Anker Technology (UK) Ltd | Suite B, Fairgate House, 205 Kings Road, Tyseley, Birmingham, B11 2AA, United Kingdom



This product is designed and manufactured with high quality materials and components, which can be recycled and reused.



★ This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

IC Statement

This device complies with Industry Canada licenceexempt RSS standard(s). Operation is subject to the

EN 13

following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil nedoit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

IC RF Statement:

When using the product, maintain a distance of 20cm from the body to ensure compliance with RF exposure requirements.

Lors de l'utilisation du produit, maintenez une distance de 20 cm du corps afin de vous conformer aux exigences en matière d'exposition RF.

14 EN EN 15