User's Manual

Electronic Key FCC ID: 2AOKM-FD12 IC: 24223-FD12 MODEL: RT-FD335, RT-FD334

This remote has lock, unlock, trunk (hatch), remote start and panic buttons; you can lock or unlock the vehicle doors, open/close trunk (hatch), remotely start the engine or activate the panic alarm with the remote transmitter.

LOCK Button:

When you press the LOCK button, it locks all the doors.

UNLOCK Button:

To unlock the driver's door, press and release the UNLOCK button on the remote once. To unlock all doors press UNLOCK button twice.

TRUNK (HATCH) Button: Pressing the TRUNK (HATCH) button twice on the remote opens and closes the TRUNK (HATCH).

REMOTE START Button: Press LOCK button once and then press the remote start button twice within 5 seconds. The vehicle will stay in the Remote Start mode for a 15-minute cycle. Press and release remote start button once to exit Remote Start mode.

PANIC Button:

When you press and hold the PANIC button for at least one second and then release it, the vehicle will start sounding the horn and flushing the park lamps. To stop the alarm, press Panic button again on the remote.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device

ADVERTENCIA IC

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS)d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis auxdeux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences.

(2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles deprovoquer un fonctionnement indésirable de l'appareil.