

Create an Atmosphere with One Simple Tool

The Ember faux fire light and portable speaker is perfect for any group gathering. Its lightweight and water-resistant design makes it easy to carry—indoors or outdoors. Simulated flame lights and 360° sound help create a lively atmosphere. What's more, it's easy to do so with Bluetooth connectivity, AUX compatibility, and three hours of playtime.


- . Mood setting, faux fire light
- Immersive audio experience with 360° sound
- · Bluetooth connectivity and AUX compatibility
- USB-C Charging cable
- Water resistant

What's Included?

- 1. Ember Portable Speaker
- 2. AUX Cable
- 3. USB-C Charging Cable
- 4. User Guide

Diagram

- 1. Metal carrying handle
- 2. Faux fire light
- 3. Light button
- 4. Power button
- 6. Volume up /Next Track
- 7. Aux/Power USB-C port
- 8. Speaker



Instructions

- 1. Press and hold the **U** button to turn the Ember Speaker ON.
- 2. The speaker will light up, indicating that it is ready to pair with vour device.
- 3. Open the Bluetooth settings on your device and select "Okko Ember", follow the instructions on your device to pair the Ember speaker. The Ember Speaker is now ready to play.
- 4. This speaker includes a TWS function that allows pairing 2 Ember speakers together to create a Stereo Surround System. To use this feature, press and hold the light button on both speakers until you hear a beep. The speakers will pair and will be ready to play your
- 5. To use AUX mode, plug the AUX cord into the auxiliary port. The speaker will switch to AUX mode automatically when the cord is
- 6. To turn the Okko Ember Speaker OFF, press and hold (1) button.

Button **Function** Changes Light Settings

 TWS Function Turn ON/OFF

 Volume Down (press and hold) Previous Track (press)

Play/Pause Music

Volume Up (press and hold) Next Track (press)

Light Feature

Press the $\sum_{i=0}^{\infty}$ button to cycle through different LED lighting modes.

Flicker (Default) Fade	ON	Gradual Fade	OFF
------------------------	----	-----------------	-----

To charge, plug the USB-C end of the charging cable into the speaker and the other end into a USB power source.

Charging time: 1.5-2 hours

Specifications

Bluetooth	V5.0	
Speaker Power	10W	
Input Power	5V/2A	
Frequency	100Hz – 10KHz	
Unit Size	7.5 x 7.5 x 14 in.	
Charging Time	1.5-2 hours	
Play Time	2-3 hours	
Battery	3.7V/2400mAh	
Water Resistance Level	IP55	

Warnings

- Do not disassemble or modify the product.
- Do not use if damaged or broken in any way.
- Keep away from flammable objects.
- . Do not try to repair this product by yourself.

Customer Support

If you have any questions about using this product, we are here to help. Call or email us and an experienced customer support representative will be happy to assist you:

1-855-GO-TZUMI or support@tzumi.com.



OKKO Ember Portable Speaker. Distributed by OKKO, NY, NY 10016. ©2021. All Rights Reserved. Made in China. All pictures shown are for illustration purposes only. Actual product may vary due to product enhancement. Other trademarks and trade names are those of their respective owners. Subject to change without prior notice.









FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technic ian for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.