



01 User Manual

True wireless earbuds TWS-A3




Thank you for purchasing our product. Please review the manual thoroughly before operating your device.


02 Packing List



03 Product picture



04 Wearing



05 How To Use

Auto power on: 1. Lift open the case cover and the earbuds will power on automatically.

Manual power on: 1. Press the touch area of the case cover and the earbuds will power on automatically.

06 Pairing

The first step: Enable the pairing mode
1. Turn on the power switch on the earbuds and connect to Bluetooth devices.

The second step: Phone searching and connecting
1. Turn on Bluetooth function of phone to search for earbuds.

07 Connection lost

Reason 1: After earbuds are connected with mobile phone, when you open mobile phone, earbuds will return to the BT connecting mode.

Reason 2: The charging case is not fully charged. Earbuds will not connect with the mobile phone when the power is low.

Reason 3: If out of the Bluetooth range, earbuds will disconnect with Bluetooth mobile phone and will reconnect to case for re-charge.

08 Incoming call

Answer a call (End a call): Double touch

Answer a call: 1. Long press of the earbuds

Music: **Music Play:** Double touch of the earbuds


Voice Assistant (Siri): Press and hold touch area of earbuds

09 Previous /Next song

Press the left earbud for previous song, press the right earbud for next song.

Reason 1: If the phone call connecting mode, the earbuds will stop music automatically after the call ends.

10 Single Mode



11 Turn Off

Method 1: Put the earbuds into the charging case. They will stop the charging mode and power off automatically.

Method 2: Press the touch area of the earbuds for 5 seconds.

12 Charging

Earbuds Charging Status: When earbuds are charging, the indicator flashes white light. After fully charged, the indicator light will stop flashing.

Case Charging Status: When the case is charging, the indicator flashes white light.

13 How To Reset

1. Turn on the power switch on the earbuds and connect to Bluetooth devices.

2. Press and hold touch area of the earbuds for 10 seconds.

Specification	
Support device	iOS
Support device	Android/Windows
Transmission distance	10M
Channels range	40MHz
Case	IPX4
Storage	2.0
Standby time	600H
Working time	About 50H
Charging time	About 1H
Earbud battery capacity	35mAh
Charging case battery capacity	350mAh
Support system	iOS/Android/Windows
Certification	CE/FCC/ROHS

14 Safety Instruction

1. Do not use the earbuds for extended periods. For the extended periods of use, please take a break every 30 minutes.

2. Do not use the earbuds in high temperatures or near heat sources.

15 Trouble Shooting

Q: Earbuds cannot be connected with mobile phone.

A: Please check the Bluetooth function of the mobile phone is turned on.

Q: Earbuds cannot be charged.

A: Please check the charging case is fully charged.

16 Questions/Answers of TWS Wireless Earbuds

Q: Why the Earbuds Case Is Not Charging?

A: Please check the charging case is fully charged.

Q: Why the Earbuds Case Is Not Charging?

A: Please check the charging case is fully charged.

17 Attention

1. Please do not use the earbuds for extended periods.

2. Please do not use the earbuds in high temperatures.

FCC Statement

This equipment does not emit radio frequency energy. This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against interference to a residential installation. This equipment generates and can also receive radio frequency energy and, if not properly installed and used, it may cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If interference does occur, please attempt to correct it by reorienting the equipment or by increasing the distance between the equipment and the interfering device. If you are unable to correct the interference, please contact your dealer for assistance.