

# SMART UNIT MANUAL

samsaraluggage.com

## SMART UNIT ASSEMBLY

Insert smart unit to port until stopper is in place.

## OPEN / CLOSED UNIT MODE

When panel is open, all smart features are available

When panel is closed only Distance Alert and Charging are available.

## ON / OFF BUTTON

- 3 second press: device on / off
- 2 short presses: open light/close light regardless to dark environment.

## LED LIGHT

- Panel can be moved for lighting different parts of the suitcase.
- Sensors should not be covered for dark environment conditions detection.
- 2 short presses will open/close light regardless to dark environment.

## USING SAMSARA APP

Distance Alert Open Suitcase Alert Led Light  
Battery& charging

## CHARGING SMART UNIT:

### USB-C

1. Download "Samsara Luggage" App from App Store or Google Play.
2. Enable Bluetooth on mobile phone
3. Pairing: the first time you use Samsara smart unit with your mobile phone you need to pair the devices:
  - Open settings bar
  - Activate application
  - To activate smart unit press the "on" button on the device for 3 seconds. - Find your Samsara device on

“device list”

- Press “connect”

Notice: the unit should not be turned on while flying (between takeoff and landing).

USB-C from unit connected to power bank or electricity via USB.

### **CHARGING MOBILE DEVICE:**

USB / USB-C from unit connected to mobile device. Press On/Off button to charge.

### **CHARGING LAPTOP:**

USB-C from unit connected to computer via USB-C.

## **APP FEATURES**

### **DISTANCE ALERT**

1. When "distance alert" square on App is yellow - feature is active. To disable press the feature square, and turn to white. 2. To choose short or long alert range:

Open settings bar choose “distance alarm” short or long preference.

### **OPEN SUITCASE ALERT**

1. When "open alert" square on App is yellow - feature is active. To disable press the feature square, and turn to white. 2. Smart unit panel needs to be open for suitcase sensors to work and alert if suitcase was opened.

### **LED LIGHT**

1. When "LED light" square on App is yellow - feature is active. To disable press the feature square, and turn to white.

2. Smart unit panel needs to be open for suitcase sensors to work and open light in dark conditions.

### **BATTERY**

Battery status is presented on the app, featuring how full it is in %.

### **LOG HISTORY**

On “settings bar” Log History presents the history of security alerts:

1. “Out of range” log with location on map.

2. “Suitcase opened” date and time (in sync with phone date and time).

Input: 5V/2A | Output: Type C: 5V/2.4A | Type A: 5V/2.1A Power: 10000mAh | Design by: Samsara  
Assmby in China

**NOTE:**

**This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.**

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:**

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.