


ESON^{STYLE}

ES11



Wireless charging speaker

ES11

Wireless charging speaker main functions

Hands-Free	Last phone number redial	Support power display
Low voltage alarm	Voice prompts	Working indicator

Instructions

Power On:

Press and hold the power button for 3 seconds to enter into the Bluetooth pairing mode, if the Bluetooth speaker has been paired with other devices, the speaker can automatically connect back to the device after it is turned on.

Short press to power on/off wireless charge function.



Power Off:

Long press MFB button 3 seconds to power off speaker.

Answer a call:

Short press "Play" button to answer a call, Short press "+" or "-" button to answer a call switch to your phone privately.

Key Description



① Play/ Pause/ Answer/ End/ Reject

② Previous song/ Volume-

③ Next song/ Volume+

④ ON/ OFF/ Wireless Charger Power on button

⑤ Line in

⑥ LED indicator

⑦ Micro USB Charge

End a call:

Short press "Play" button to end a call.

Redial last number:

Double click MFB Button to Redial last number when the speaker is connected.

Reject a call:

Double press "Play" button to refuse a call.

Play mode: Short press "Play" button to pause/play music.

Adjust volume/ Previous/next song:

Short press "+" button to next song, Long press "+" button to increase volume.

Short press "-" button to previous song, Long press "-" button to reduce volume.

Power off memory function:

Automatic connection previous device function.

Remember previous volume level.

Low battery alarm, Power saving automatic power off function:

Voice prompts that the battery is low (Low-power prompt tone broadcast once when the low-voltage prompt voltage 7.2V), Bluetooth speaker will automatically shut down when the battery voltage is 6.8V

Charging Indicator:

The indicator light is red for charge, The indicator will be off when charging fully.

Power off automatically:

On Bluetooth ready to paired, pause music and AUX mode about 10 minutes, The speaker will power off automatically if your speaker do not work after 10 minutes.

Other instructions:

Battery display: The battery power will be displayed in the upper right corner when the speaker was connected with iPhone or other device (The function display may be related to different phone model).

Problem & Solutions

- Loss contact: Check if the speaker is in pairing mode.
- Staccato: Check if the distance is longer than 10 m. Is there any obstacle? Is the power of batteries enough?
- Doesn't Work: Check if the batteries work.



ESON^{STYLE}

The Bluetooth work mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Eson Technology Co.,Ltd is under license. Other brands names are the property of their respective owners.

Design and specifications are subject to change without notice.



Made in China

FCC STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction..