

Instruction Manual

Model: BT-001

Bluetooth Transmitter

INSTALLATION

Installing the Bluetooth Transmitter

1. Plug the included USB Wall Adapter into a standard ac outlet. Connect the USB end of the cable to the USB port of the Wall Adapter and the Micro USB end of the cable to the DC 5V IN of the Bluetooth Transmitter. Red LED on the Bluetooth Transmitter will flash slowly.
2. Connect the audio output of the source device (TV, DVD player, etc) to the AUX IN of Bluetooth Transmitter with the included 3.5mm Aux cable or RCA cable.
3. Press and hold the Power ON/OFF button for 3 seconds to turn on the Bluetooth Transmitter, Blue and Green LED lights will flash alternatively (besides the Red solid LED light).

Connecting the Bluetooth Headphone to the Bluetooth Transmitter

1. Press and hold the Power ON/OFF button for 3-4 seconds to turn on the Bluetooth Headphone, indication tone would be heard and the LED will flash red and blue alternatingly.
2. Place the Headphone and Transmitter so that they are no further than 1 foot apart.
3. Short press the Search button of the Transmitter once to start searching and matching.
4. If connection is successful, another indication tone would be heard and the LED on the Headphone will flash Blue slowly. And Green LED light on the Transmitter will stay on (besides the Red solid LED light).
5. You can enjoy the audio output of device (TV, DVD player, etc) through the Headphone.
6. Press and hold the Volume Decrease or Volume Increase button to decrease or increase the volume.

Bluetooth Transmitter:

1. Power source: DC 5V
2. Transmitting distance: 33 feet

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the

following

two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may

cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for

compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B

digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed

and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference to radio or

television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following

measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.