





Restrict Band NVNT n20 5260MHz Peak




Restrict Band NVNT n20 5260MHz Average






Restrict Band NVNT n20 5320MHz Peak




Restrict Band NVNT n20 5320MHz Average






Restrict Band NVNT n40 5270MHz Peak




Restrict Band NVNT n40 5270MHz Average






Restrict Band NVNT n40 5310MHz Peak




Restrict Band NVNT n40 5310MHz Average






Restrict Band NVNT ac20 5260MHz Peak



Restrict Band NVNT ac20 5260MHz Average



Shenzhen LCS Compliance Testing Laboratory Ltd.


Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China

Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com


Scan code to check authenticity



Restrict Band NVNT ac20 5320MHz Peak




Restrict Band NVNT ac20 5320MHz Average






Restrict Band NVNT ac40 5270MHz Peak




Restrict Band NVNT ac40 5270MHz Average








Restrict Band NVNT ac40 5310MHz Peak




Restrict Band NVNT ac40 5310MHz Average








Restrict Band NVNT ac80 5290MHz Peak



Restrict Band NVNT ac80 5290MHz Average





E.5 Frequency Stability


Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	ac20	5260	Ant1	5259.98	-20000	-3.8	25	Pass
NVNT	ac20	5300	Ant1	5300	0	0	25	Pass
NVNT	ac20	5320	Ant1	5320	0	0	25	Pass
NVNT	ac40	5270	Ant1	5270	0	0	25	Pass
NVNT	ac40	5310	Ant1	5310	0	0	25	Pass
NVNT	ac80	5290	Ant1	5290	0	0	25	Pass








Test Graphs



Freq. Stability NVNT ac20 5260MHz Ant1



Freq. Stability NVNT ac20 5300MHz Ant1










Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	ac20	5260	Ant2	5259.98	-20000	-3.8	25	Pass
NVNT	ac20	5300	Ant2	5300	0	0	25	Pass
NVNT	ac20	5320	Ant2	5319.98	-20000	-3.76	25	Pass
NVNT	ac40	5270	Ant2	5270	0	0	25	Pass
NVNT	ac40	5310	Ant2	5310	0	0	25	Pass
NVNT	ac80	5290	Ant2	5290	0	0	25	Pass








Test Graphs



Freq. Stability NVNT ac20 5260MHz Ant2



Freq. Stability NVNT ac20 5300MHz Ant2









E.6 Duty Cycle


Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5260	Ant1	94.56	0.24	0.91
NVNT	a	5300	Ant1	94.65	0.24	0.91
NVNT	a	5320	Ant1	94.56	0.24	0.91
NVNT	n20	5260	Ant1	93.77	0.28	1.07
NVNT	n20	5300	Ant1	93.77	0.28	1.07
NVNT	n20	5320	Ant1	93.77	0.28	1.07
NVNT	n40	5270	Ant1	92.71	0.33	1.27
NVNT	n40	5310	Ant1	92.71	0.33	1.27
NVNT	ac20	5260	Ant1	93.72	0.28	1.06
NVNT	ac20	5300	Ant1	93.72	0.28	1.06
NVNT	ac20	5320	Ant1	93.72	0.28	1.06
NVNT	ac40	5270	Ant1	92.75	0.33	1.26
NVNT	ac40	5310	Ant1	92.75	0.33	1.26
NVNT	ac80	5290	Ant1	89.82	0.47	1.86






Test Graphs

Duty Cycle NVNT a 5260MHz Ant1




Duty Cycle NVNT a 5300MHz Ant1






Duty Cycle NVNT a 5320MHz Ant1




Duty Cycle NVNT n20 5260MHz Ant1






Duty Cycle NVNT n20 5300MHz Ant1




Duty Cycle NVNT n20 5320MHz Ant1






Duty Cycle NVNT n40 5270MHz Ant1




Duty Cycle NVNT n40 5310MHz Ant1






Duty Cycle NVNT ac20 5260MHz Ant1




Duty Cycle NVNT ac20 5300MHz Ant1






Duty Cycle NVNT ac20 5320MHz Ant1




Duty Cycle NVNT ac40 5270MHz Ant1






Duty Cycle NVNT ac40 5310MHz Ant1



Duty Cycle NVNT ac80 5290MHz Ant1






Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5260	Ant2	94.65	0.24	0.91
NVNT	a	5300	Ant2	94.56	0.24	0.91
NVNT	a	5320	Ant2	94.56	0.24	0.91
NVNT	n20	5260	Ant2	93.77	0.28	1.07
NVNT	n20	5300	Ant2	93.77	0.28	1.07
NVNT	n20	5320	Ant2	93.77	0.28	1.07
NVNT	n40	5270	Ant2	92.71	0.33	1.27
NVNT	n40	5310	Ant2	92.71	0.33	1.27
NVNT	ac20	5260	Ant2	93.72	0.28	1.06
NVNT	ac20	5300	Ant2	93.82	0.28	1.06
NVNT	ac20	5320	Ant2	93.72	0.28	1.06
NVNT	ac40	5270	Ant2	92.75	0.33	1.26
NVNT	ac40	5310	Ant2	92.75	0.33	1.26
NVNT	ac80	5290	Ant2	89.65	0.47	1.86






Test Graphs

Duty Cycle NVNT a 5260MHz Ant2




Duty Cycle NVNT a 5300MHz Ant2






Duty Cycle NVNT a 5320MHz Ant2




Duty Cycle NVNT n20 5260MHz Ant2






Duty Cycle NVNT n20 5300MHz Ant2




Duty Cycle NVNT n20 5320MHz Ant2






Duty Cycle NVNT n40 5270MHz Ant2




Duty Cycle NVNT n40 5310MHz Ant2






Duty Cycle NVNT ac20 5260MHz Ant2




Duty Cycle NVNT ac20 5300MHz Ant2






Duty Cycle NVNT ac20 5320MHz Ant2




Duty Cycle NVNT ac40 5270MHz Ant2





Duty Cycle NVNT ac40 5310MHz Ant2



Duty Cycle NVNT ac80 5290MHz Ant2

