

## Welcome Guide

### 4-IN-1 Magnetic Wireless Charger

Thanks for your support of this magnetic wireless charging station, please read this guide carefully before using this product.

#### What's Included

#### Wireless Charging Dock-Specifications

Type Input	5V/3A, 9V/2A, 9V/2.22A, 9V/3A
Wireless Output (iPhone)	5W, 7.5W, 10W (MAX)
AirPods Output	5W (MAX)
Watch Output	2W
USB-A Output	5V/1A (MAX)
Poppin Output	9V/2A (MAX)
Product size	4.9" x 3.4" x 3.4" inch
Weight	7.9 oz (140g)

#### Wireless Charging Dock-Product Structure

- ① Wireless Charging Area for Power Bank # P13
- ② Popping # P13
- ③ TWS Earphone Indicator / Power Indicator # P13
- ④ Wireless Charging Area for TWS earphone or other Qi-enabled devices # P13
- ⑤ Non-slip Mat # P15, P16
- ⑥ Wireless Charger for Apple Watch # P15, P16
- ⑦ Type-C Input # P11
- ⑧ USB-A Output # P12

#### Wireless Charging Dock-LED Usage

Standby mode	Red light on
Charging mode	Green light on
Charging full	Green light on
FOD	Red-green light flash

**Connected Indicator:** When powered the source, the LED light near the earphone wireless charging area is red on. When you charge earphone, this LED light is changed to earphone wireless charging indicator.

#### Wireless Charging Dock-Stand

Please adjust the comfortable view angle (30°-80°) according to your need.

#### Apple Watch Charger-Product Structure

- ① Wireless Charging Area for Apple Watch # P16
- ② Apple Watch Charger Case # P16
- ③ Type-C Input # P15
- ④ Watch Charging Indicator # P6

#### Apple Watch Charger-LED Usage

Standby mode	Green light
Charging mode	Green light breathing

#### Power Bank

#### Power Bank-Specifications

Battery Capacity	5000mAh
Rated Capacity	3250mAh
Type Input	5V/2.5A, 9V/2A, 12V/1.5A (Max 18W)
Type-C Output	5V/2.4A, 9V/2.22A, 12V/1.5A (Max 20W)
Wireless Output	5W, 7.5W, 10W (MAX)
Simultaneous Output	5V/3A
Charging Efficiency	~2.75%
Transmission Distance	6mm
Product size	4.95" x 3.7" x 0.53" inch
Weight	5.83 oz (165g)

#### Power Bank-Product Structure

- ① Wireless Charging Area # P13
- ② Power Rate Indicator # P9
- ③ Wireless Charging Status Indicator # P9
- ④ Pass through charging via Type-C Input/Output # P20, P21
- ⑤ Heat Dissipation Hole # P18
- ⑥ Switch # P18
- ⑦ Foldable & Adjustable Aluminum Stand (0°-180°) # P10
- ⑧ Copper Sheet for the Charging Dock # P13

#### Power Bank-LED Usage

Power 67%-100%	3
Power 34%-66%	2
Power 1%-33%	1

Wireless Charging Working Property	Blue LED Breathing
Fully Charged	Blue LED Breathing
FOD	Blue LED Flashes

#### Power Bank-Stand

The table stand of this power bank is not only for the angle-adjusting, but also can be folded to flat for travelling. You can adjust the angle (0°-180°) according to your need. When you need not to charge, you can use it as a simple MagSafe stand to support your phone (in horizontally or vertically). Just need depressing the switch by double quick press. **Please Note:** Certain Vibration will restart the Charging Again.

#### Wireless Charging Dock-How To Use

Please use the included PD20W adapter and cable to connect this wireless charging dock to the power source.

**Note:** Please use our PD 20W adapter (not included) in the correct input port (Type-C port on the bottom). USB-A and the Type-C port on the top is just output port.

#### Wireless Charging Dock - Extra USB Output

Using the USB-A to Type-C cable (Not Included), connect the USB-A cable into the dock and the other side to the devices you want to charge, such as iPad, phone, earphone, Switch and so on.

#### Wireless Charging Dock - Wireless Charging for power bank

After connecting the power source, please put the power bank in the charging dock and make sure that the metal contact of the power bank is touched with that of charging dock. It will charge automatically. When the power bank is charged, it's green light flashing. When it's full charged, 3 indicators keep green light on.

**Note:**

- The magnetic wireless power bank is mainly used for iPhone 12, iPhone 13, iPhone 14 series, or phones with MagSafe compatible ring attached. It will charge your phone automatically via the built-in magnetic wireless charging. Max to be 15W. iPhone series is 7.5W due to iPhone's restrict.
- The power bank has a built-in vibration sensor when you place the iPhone or AirPods 3 in the charging area, then charging will automatically turn on. (If you need want to use the rapid to trend function, just double click on the power switch to turn off the charging function).

#### Wireless Charging for phone

Please fit the product with the back of your iPhone (12, 13, 14 series) or other wireless charging phone (which with MagSafe case) if you charge your phone automatically via the built-in magnetic wireless charging. Max to be 15W. iPhone series is 7.5W due to iPhone's restrict.

**Note:** If power bank and phone are charged simultaneously, it's fast wireless charging for phone while power bank is in slow charging. When the phone full charged, the power bank is in fast charging mode.

#### Wireless Charging Dock - Wireless charging for Apple Watch

Please remove the watch charger and inserted it into the corresponding position of charging dock.

**Note:** This product is only available for Apple Watch. If Samsung watch, it's not compatible.

#### Wireless Charging Dock - Wireless charging for Apple Watch

Please make sure your Apple Watch is corresponded to the area of the wireless charger Apple Watch. It will automatically detect the Apple Watch and charge it.

#### Wireless Charging Dock - Wireless charging for TWS earphone

Please lay down your earphone on the charging area and then it will automatically detect and charge (if Mag).

#### Power Bank-Use Of Switch

**Single Press:** Turn on  
**Double Press:** Turn off

Press the switch once to power on the product the battery indicator will light up. There is in the standby state and other devices can be charged. Press the switch twice continuously, then the output will turn off.

**Tip:** In standby mode it will turn off automatically after about 35 seconds without performing either.

#### Power Bank-Wireless Charging Operation

Please fit the product with the back of your iPhone (12, 13, 14 series or AirPods 3) or other wireless charging phone (which with MagSafe compatible ring attached). It will charge your phone automatically via the built-in magnetic wireless charging. Max to be 15W. iPhone series is 7.5W due to iPhone's restrict.

**Note:**

- The magnetic wireless power bank is mainly used for iPhone 12, iPhone 13, iPhone 14 series, or phones with MagSafe compatible ring attached. Please note some of MagSafe compatible (not from the 1st engine not work). And it can also used with AirPods 3.
- The power bank has a built-in vibration sensor when you place the iPhone or AirPods 3 in the charging area, then charging will automatically turn on. (If you need want to use the rapid to trend function, just double click on the power switch to turn off the charging function).

#### Charging The Power Bank

Please recharge the product when the power or battery is low.

- Using the included cable (like USB-A to Type-C Cable or C to C), connect the USB-A or C connector into QC/PD adapter and the Type-C connector to the input connector of the power bank.
- During charging, Green LED indicators will flash to show charging status.
- When charging is complete the Green LED indicators will stay on.

**Pass Through Charging:** You can put (Stick to) your iPhone 12/13/14 series, AirPods 3 on the wireless charging area and connect this power bank to the power source (9V or QC Adapter). It will charge the power bank itself and your iPhone 12/13/14/Airpods 3 at the same time.

**Note:** While charging, the phone will be in fast charging and power bank is in a slow charging. When phone is fully charged, the power bank is in fast charging mode.

#### Power Bank Operation

- Insert the charging cable Type-C end into Output.
- Plug the other end of the cable into a terminal such as phone.
- Using the USB-A to Type-C or C-C cable (Not included), connect the C cable into the power bank and the other side to the devices you want to charge, such as iPad, phone, earphone, Switch and so on.

**Note:** When the power bank only charge one device, whether C port or wireless charging area, the (output) support fast charging. If two device, the maximum output power is 5W/A, no fast charging.

#### Warning

- Do not drop, misuse or apply excessive force to your power bank. Power banks contain batteries and a circuit board with fragile components that can be damaged if misused.
- If your power bank swells or bulges, stop use immediately and dispose of the power bank in an appropriate manner.
- Store power bank in a cool and dry place. Do not store in hot or humid environments.
- All power banks have safety power cut-off features to stop overcharging & overheating.
- When charging a device the power bank may feel warm, this is a normal operating condition & should not be cause for concern.
- It is normal that the charger and your smart phone will be hot under operating conditions and it may be more hotter when charging and using at the same time both as playing music.
- In normal conditions, battery performance will decline over several years.

#### Remarks

When your wireless power bank works improperly

- Make sure there is no any obstacles on the wireless power bank, such as magnet, metal, credit card and other foreign objects.
- When the wireless power bank is over-heating, take your mobile device away from your wireless power bank and the power bank will stop charging automatically when you're heating. Please try charging again when the wireless power bank cooling down.

Magnets, Credit Cards, Metal Cases

FC CE RoHS Recycle Made in China

品名:	DMS03-套装-说明书	规格:	100g 双胶纸 四色 双面印刷 对折+风琴折 尺寸:80x120 mm
版本:	20220901		
制作:	李志敏		
料号:			

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.