

正


Warning

When your wireless power bank works improperly


1. Make sure there is no any clutter on the wireless power bank.
2. When the wireless power bank is over-heating, take your mobile device away from your wireless power bank, and the power bank will stop charging automatically when over-heating. Please try charging again when the wireless power bank cooling down.

Remarks


It's normal that this charger and your smart phone will be hot under operating conditions, and it may be more hotter when charging and using at the same time (such as playing music)




No washing



No metal objects on the surface






No knocking



User Manual


In the box:

User manual × 1 Wireless power bank × 1 Micro-usb charging cable × 1

Product Diagram

Wireless Charging Area



Note:

Thank you for your acquisition of this compact power bank wireless charger, compatible with all Qi devices like Samsung S7/S7 edge, S8/S8 edge, S9/S9 edge, S10/S10 edge, S20 Series, Note 20 Series, iPhone 8/8 Plus, iPhone X, iPhone XR, iPhone XS, iPhoneXS MAX, iPhone 11, iPhone 11 Pro, iPhone 11 Pro MAX, iPhone 12, iPhone 12 Mini, iPhone 12 Pro, iPhone 12 Pro Max.

For optimum performance and safety, please read this manual carefully before using this product.

反

Specifications:

Capacity: 10000mAh
 Micro B Input: 5V/2A, 9V/2A, 12V/1.5A
 Type-C Input: 5V/3A, 9V/2A, 12V/1.5A
 Transmission Distance: ≤6mm

Type-C Output: 5V/2.4A, 9V/2.3A, 12V/1.7A
 USB Output: 5V/3A, 9V/2A, 12V/1.5A
 5V/4.5A(SCP)
 Wireless Output: 15W
 Charging Efficiency: ≥75%
 Product size: 104 x 71.5 x 20 mm

How to Use

Switch

Use of switches

Press the switch once to turn on the product, the battery indicator will light up. Then it is in the standby state and other devices can be charged. In the power on state, and hold the power button for 5 seconds to turn off the power.

Tips: In standby state, if you do not perform other operations, it will automatically shut down after about 20 seconds. If you need to use it again, please press the switch again.

Indicator

Power Rate Indicator


0%-24% 25%-49% 50%-74% 75%-100%

The battery indicator is steady blue.

Wireless Charging Status Indicator


Green light on, wireless charging.
 Red light on, wireless charging is standby.
 Red light and the green light flashes alternately, wireless charging is abnormal.

Wireless Charging



Please fit the product with the back of your iPhone, it will charge your iPhone automatically via the built-in magnetic wireless charging, Max to be 10W.

Charging



In

When the product is out of power or low battery, then you need to charge the product. You can use the standard USB charging cable with Micro USB connector to connect this product, and plug the USB A into a 5V/2A charging device such as a car charger, household appliances, etc. to charge the product.

Out

1. Insert the USB charging cable USB A end into Output.
2. Plug the other end of the cable into a terminal such as a mobile phone.
3. Press the switch button and the power is discharged to charge the terminal such as a mobile phone.

SmartPhones Tablettes GameBoy GoPro E-Cigarette

品名:	Mag10000W-PD22.5W-中性说明书	规格:	128g 双铜 黑白 双面印刷 对折 尺寸:90x140 mm
版本:	20210223		
制作:	李志敏		
料号:			

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.