



One Click Casting

OnCollab AT-C/AT-H Quick Start Guide


AVAOCATQSG V1.0
82445-00070-33010-T



• Connections and Indicators

C USB-C Connections

Connect AT-C to the USB-C port on the computer.
*The USB-C port must support DP signal output.



1 Large Button - Projection

Display the status of the projection function.
Press lightly to start/stop projection.

2 Small Button - Video Conference

Display the status of the video conference devices.
Press lightly to mute/unmute connected speaker
and microphone.

H HDMI & USB-A Connections

Connect AT-H to the HDMI & USB-A port
on the computer or another power source.





Copyright 2024 Naritech Corp. -
All rights reserved. All trademarks and registered trademarks are the
property of their respective owners and are used under the fair use doctrine.
www.naritech.com/AVA



OnCollab AT-C/AT-H
Product Registration

When using the AT-C/AT-H for the first time, please pair the unit with your OnCollab device.

• Pairing



1 USB 3.0 Connections

Connect the AT-C/AT-H to the USB 3.0 port of the OnCollab device. The device will enter pairing mode.

2 Enter the Wifi password

After entering the password, the device will start pairing.

3 Pairing Successful

When the device has successfully paired, unplug the AT-C/AT-H.

• Usage Instructions



1 Setup your OnCollab Device

Turn on and setup the OnCollab Device that has been paired with AT-C/AT-H.

2 USB-C/HDMI Connections

Connect the AT-C to the USB-C port. Connect the AT-H to the HDMI & USB port.

3 Wait for the Light Indicator

Wait until the large button emit a constant blue light before using it.

• LED Indicators

1 Large Button - Projection



Standby, ready for projection.



Projection in progress.



Moderator Control Activated.

2 Small Button - Video Conference



Standby.



OnCollab camera detected.



OnCollab speaker & microphone detected.



OnCollab speaker & microphone are in use.



OnCollab microphone is muted.



3 Small and Large Button - Other Status



Establishing connection with Wi-Fi.

*If the connection cannot be established continuously, please check the network is normal or the password is entered correctly during pairing.



Searching for OnCollab devices.

*If OnCollab devices cannot be found continuously, please check if the OnCollab device is connected to the correct network or repair it.



No audio/video output from the computer's USB-C/HDMI port.

Federal Communication Commission Interference Statement This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

RF exposure warning

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.