

<h3>ShotKam Controls</h3> <p>WITH SHOTKAM OFF, HOLD POWER BUTTON:</p> <ol style="list-style-type: none"> 1. 0-2 Seconds = <u>Standard Mode</u> 2. 2-10 Seconds = <u>Wi-Fi Mode</u> 3. Click Once with 1s = Constant record 4. Click Once after 1s = Power OFF 5. When ON, 5 Seconds = Reboot <p>* Click twice to power off when in sleep mode.</p> <p>SOLID LED's:</p> <ul style="list-style-type: none"> Initial Warm Up Ready Connected to Wi-Fi Fully Charged <p>FLASHING LED's:</p> <ul style="list-style-type: none"> Sleep Mode Recording Video Charging + Storage Full 	<h3>Quick Start Guide</h3> <ol style="list-style-type: none"> 1. Remove rear twist-off cap to access USB port. NOT front cap with lens. This CANNOT be removed. 2. Plug USB cable into ShotKam and personal computer. 3. For Windows PC users: <ul style="list-style-type: none"> • Open File Explorer  then go to "ShotKam" under This PC (left sidebar) For Apple Mac users: <ul style="list-style-type: none"> • Open Finder  then go to "ShotKam" under Devices (left sidebar) 4. Run "ShotKam Software" <p>* ShotKam Software is a Java application. If you need an updated version go to: www.java.com</p> <ol style="list-style-type: none"> 5. Select your target type, gun type, and reticle choice. 	<h3>Mounting to the Barrel</h3> <p>* Mount 3 to 10 inches from muzzle end of the barrel (not on barrel porting holes.)</p> <ol style="list-style-type: none"> 1. With the <u>USB connector up</u>, place brackets around ShotKam. 2. Ensure that the rubber ridges on the brackets align with the grooves of the ShotKam. 3. Using the Allen key, tighten the brackets around the barrel. Screw on the rear cap. 4. Ensure that the camera is directly under the barrel. Tighten the screws. Do not overtighten. 
<h3>Using Wi-Fi</h3> <p>The ShotKam App allows the user to control the settings and adjust the reticle (point of aim).</p> <ol style="list-style-type: none"> 1. Download the "ShotKam" App using the Apple App Store or Android Google Play.  2. Turn ON the ShotKam's Wi-Fi Mode by holding the power button 2+ seconds. 3. Go into the Smartphone/ iPad/ Tablet SETTINGS page and select "Wi-Fi", then "ShotKam" to connect.  4. Open the ShotKam App and control the configurations. 5. With the ShotKam mounted, look along the <i>unloaded</i> gun barrel, and adjust the reticle accordingly. 	<h3>What's Included in Your Purchase:</h3> <ul style="list-style-type: none"> • ShotKam Camera • USB cable and wall charger • Hard camera case • Allen key to tighten screws • Spare silicon rear cap • Spare front lens cover • Spare rubber mounting pads • Spare "O" rings • Spare mounting screws 	<h3>Watching the Videos</h3> <ol style="list-style-type: none"> 1. Connect the ShotKam to the computer using USB cable. <p>For Windows PC users:</p> <ul style="list-style-type: none"> • Open File Explorer  → ShotKam → download "VLC Media Player" (it's safe and free).  <p>For Apple Mac users:</p> <ul style="list-style-type: none"> • Open Finder  → ShotKam → download "VLC Media Player". <p>To make VLC your default player, visit our FAQ page or search in Google.</p> <ol style="list-style-type: none"> 2. Then File Explorer/Finder → ShotKam → DCIM folder → 100_KAM. <h3>Remark:</h3> <p>The product needs to be used with the bracket</p>

Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by BVT Video Technology Shenzhen Limited

may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF exposure statement:

The transmitter must not be colocated or operated in conjunction with any other antenna or transmitter. This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a Minimum distance of 20cm between the radiator and any part of your body.