


Meet the Wi-Fi Hub



Input: 100–250V ~ 50/60Hz

WiFi Frequency: 2.4GHz only

Protocol: IEEE 802.11b/g/n

APP: SmartLife/Tuya

Total Number Connected: 32

Working Temperature: -10°C~45°C

Working Humidity: 10%-90% RH (no condensation)

For Indoor Use Only

Pair the Wi-Fi Hub and add the device

1. Pair the WI-FI Hub

1.1 Long press the Wi-Fi Hub Control button for 5s until the green light flashes quickly, and enter the pairing mode.

Then Turn on the phone's bluetooth

1.2 Tap "Add device" or "+" to add the smart device in app.

Select "Gateway Control " > "Socket Gateway(BLE)".

Waiting for connecting to be 100%. Edit the name of your Hub completed.

2. Timer and gateway associated

2.1 Press and hold device button on your timer around 5 seconds until the LED light rapidly flashing

2.2 Tap "Add device" to add the timer in Gateway.

Select "Add new device " .

2.3 Waiting for connecting to be 100%. Edit the name of your device completed.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.