

Thank you for purchasing JH-9103 wireless earbuds. It is a 3 in 1 high quality earbuds system, which creatively build-in Speaker and power bank. Powerful bass and more than 1200 mAh power bank, that called Energy Bar.

JH-9103 gathering newest technology, supports all functions control by touch lightly and keep hifi music replay.


Focus on improving and enhancing user experience, comfortable wearing, ergonomic in-ear design fit the auricle perfectly.

free from pressure and distending pain for long time wearing.

For best experience of using JH-9103, pls read this manual carefully before your initial using earbuds.

#### Safety Rules

1. To be safe, comply with all rules mentioned in the manual.
2. Away from the sharp edge, uneven surface, metal parts accessories and package.
3. Do not open, dismantle or repair the earbuds, which will cause accident happened, fire, electronic board breakdown or damage the earbuds completely, all these excluded in warranty.
4. Do not wipe or clean the earbuds with old or any volatile liquids.
5. Do not use the earbuds in places where potential personal safety existing in risk and danger.



Packing details

### Quick Guide

#### 1. Connecting Phone

- A. Press the "L" earbud panel, LED light on, and hearing :Power On
- B. Press the "R" earbud panel, LED light on, and hearing :Power On
- C. "L" and "R" will connect each other for TWS mode, and hearing :Pairing successful. left channel from "L" and right channel from "R".
- D. "L" shows light blue and red blinking alternatively, and reminding: pairing
- E. Turn on the bluetooth Function of the phone, searching bluetooth device "JH-9103"
- F. Select "JH-9103", and connect it, hearing: connected successful. Enter 0000 if password needed

#### ATTENTION:

PARING TO PHONE ONLY FOR FIRST TIME CONNECTING. EARBUDS WILL CONNECTING THE PHONE WHICH ALREADY CONNECTED AUTOMATICALLY FOR EACH TIME WHEN POWER ON

#### 2. Battery Cabinet

- A. put the earbuds into the case, will charge the earbuds directly until fully.
- B. Click the ON/OFF button of the case, to display the battery charging percentage, and charge the earbuds manually.
- C. During charging, Double Click the ON/OFF button, LED light in the case will be off and stop charging to earbuds and stop the speaker system
- D. Long press 3s the button to turn on (turn off) the speaker function, put the earbuds into the case, speaker will continue play the music through Earbuds.

#### 3. Touch Function definition:

- A. Answer calling :one click L touch panel during the coming call ringing
  - B. Hold on: one click L touch panel during answer calling
  - C. Reject calling :Double click L touch panel during the call ringing
  - D. Redial the last number: Double click while Earbuds stand by
  - E. Play music: one click L or R touch screen while with phone connected and music app is ready
  - F. Pause: one click L touch screen while the music is playing.
  - G. Skip to Next: Long press L touch panel 2s, and beep tone, then skip to next
- ATTENTION:**  
PLEASE REMOVE THE PROTECTION SHEET ON THE EARBUDS WHEN START INITIAL USING  
DURING PHONE CALL COMMUNICATION, ONLY LEFT CHANNEL WORKS  
PLEASE AWAY THE RADIO INTERFERENCE AND AVOID TOO NOISY ENVIRONMENT WHEN USING EARBUDS.  
PLEASE REPLAY THE HIGHT QUALITY FORMAT OF MUSIC OR LOCAL MUSIC OF THE DEVICE

#### 4. Engineering Mode

- A. R Earbuds can be the mono earbud to connect with phone
- ATTENTION:** No recommended- R earbud connect with phone as mono communicator as it causing the Stereo mode can't work normally.
- SOLUTION:** 1. Enter the bluetooth device connection list, clean up the connection of two earbuds (same device name list on the phone)

2. reset the step that 'connecting Phone'

### Product Parameter

#### 1. Earbud parameters

Earbud battery: Polymer lithium battery 40mAh  
Bluetooth Version: 4.2  
Peration Voltage: 3.2V-4.2V  
Speaker Bandwidth: 20-20KHz  
Earbud frequency: 2.4-2.48GHZ  
Compatible protocol: A2DP/HFP/HSP/AVRCP  
Earbud working range: 10M  
Single earbud calling or music time: 2h  
Single earbud standby time: 3 Months

#### 2. Charging case Parameter

Charging case battery: Polymer Lithium battery 1200mAh  
DC Charging Voltage: DC 5V  
Speaker Amplifier: 3W  
Speaker Bandwidth: 20HZ-20KHZ  
Charging USB output : 5V/1A  
Standby time: 6 Months

#### FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.  
Increase the separation between the equipment and receiver.  
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

**RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## Warranty Card

Product name :	Model :
Sale Date :	
Contact Number :	
Address :	
Defect :	

#### Terms of Warranty

1. We provide 180 days warranty for the function defect of main body, the main body and package should be kept integrity, no man-made surface break. The accessories are not included in the warranty.
2. The warranty service is expired based on ordinary using of product, all malfunction and damaged caused by man-made broken, unauthorized repairs and alteration, incorrect use are not included in the warranty.
3. The warranty card should be provided for each warranty claim. If it can not be provided or unilateral amendment, our company will have rights to regard it as non-warranty.

Tip: The product label is too large to be reflected on the product.

We are already putting the label on the outer box and the outer box can see the label!



## User manual