

CareKii Product Operation Instruction

CareKii is a multifunctional wearable reminder and activity tracker that works with the smartphone.

1. Charge the CareKii

Place the CareKii in the center of the wireless charger, the green LED on the CareKii should blink once and the blue LED on the wireless charger will stay on. The blue LED on the charger will be off when the battery is fully charged.

2. Download the app

Download the CareKii Android or iOS app from Google Play Store or Apple App Store. All functions on the CareKii can be active and controlled by the app.

3. Register and connect the CareKii

Open the CareKii app on your smartphone, tap a function you want to use. The system should remind you to register a CareKii. Place your CareKii right beside your smartphone and tap Continue. When you hear a beep, your CareKii is successfully registered. Multiple CareKii's can be registered in different functions. You can edit and manage all registered CareKii's in settings.

4. Attach and run the CareKii

Attach the CareKii after registration.

- a. For Drink Reminder, attach the CareKii clip to the side of the cup by supplied double sided tape. Then snap the CareKii into the clip. If you need to wash the cup, remove the CareKii from the clip before wash. CareKii is not designed to be waterproof. If water is splashed on CareKii, wipe it off as soon as possible. Go to settings to set the daily

goal and remind method and interval. Drink time and amount will be automatically saved in the CareKii.

- b. For Slouch Reminder, pass the attached string through the clip and wear it around your neck, keeping the CareKii to the upper back. To set the upright target: open the app, stay upright and in settings tap SET TARGET, your target will be set when you hear a beep. Then you can bend a bit to select which slouch level you want to alert, then tap SET ALERT. In Settings you can also set different remind method.

Breaktime Reminder and Step Counter can be used together with Slouch Reminder. Just turn it on and set all the reminder timer and intervals in Settings.

Breaktime Reminder and Step Counter can also work separately from Slouch Reminder, in this case use the attached clip to attach the CareKii on clothes, pants or belt.

- c. For Sleep Monitor, attach the CareKii by clip to your underpants. In the app set the flat position first, you are ready to go. All sleep status data will be saved in the CareKii.

5. About the data

CareKii will keep data for all functions for 3 days, you must connect CareKii with your phone to download the data before it's being erased.

Tap on the temperature icon to switch between Celsius and Fahrenheit. If the temperature is not accurate, calibrate the temperature in Settings. Use a thermometer to measure the temperature around the CareKii and enter the temperature to calibrate. Do not calibrate the temperature when the CareKii is in charging. Charging will increase the temperature.

Tap on the Update icon to download the new data.

Navigate the previous day data by swipe on the day chart if it's available. Week data and month data will be calculated from day data and can be hide and unhide by tapping on the Week and Month tab.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.