




Wi-Fi Smart Switch


Model:MINI



Parameter:
 Input: AC 100-240V 50/60Hz 10A Max
 Output: AC 100-240V 50/60Hz 10A Max
 Wi-Fi: IEEE 802.11 b/g/n 2.4GHz
 Material: PC V0
 Size: 42.6x42.6x20mm

Checklist before using the device

- Your smart phone or tablet has connected to a 2.4G WiFi with internet.
- You have the correct WiFi password.
- Your smart phone or tablet must have access to APP Store, Google Play.
- Make sure that your router is MAC-open.



User Guide


- 1 Start with "EWelink" APP.



- 2 Register an EWelink account.
- 3 If you have EWelink account, just log in.


- 4 Please wire the device according to the marking on the cover.

ON/OFF operating principle:
 The connected appliances work/stop through live wire power on/off. The device must be powered by L and N.




Warning: S1 and S2 can only be connected to the two ends of the wall, and cannot be connected to strong power such as zero-fire line.


- 4.1 The wiring diagram to connect the electrical appliance.



- 4.2 The wiring diagram to connect the light.



- 5 When the device is powered on, it is ready to be paired in the Quick Pairing Mode(Touch), and the Wi-Fi indicator blinks twice and last for one second.



Warning: The antenna has strong internal power and do not break the insulation.

Note: If the device fails to connect to the network or a new network, please press and hold the configuration button for 5 seconds until the blue Wi-Fi LED indicator blinks fast, and then re-pair the device with your eWelink account on the app.

- 6 Tap + on EWelink app.



- 8 Input your WiFi SSID & password.

- 9 Name your device to complete.

- 10 When the WiFi LED is on, the device is online. Start to control now!

Using With TH Sensor :

By inserting our TH sensor (if bought) into the switch, you can view real-time temp. and hum. on APP. Besides, you can enable the **Auto Mode**: set a temp. or hum. range to auto-turn on/off.

Note: Please flip off the main breaker before a qualified electrician install the device or do the maintenance. It is not allowed to touch the device when it is in use.

Q: My device on the app stays "Offline" ?

A: The new added device needs 1min to connect to WiFi and the Internet. If it stays offline for a long time, please judge the problem by the WiFi LED status:

WiFi LED quickly blinks one time every second:

- Device failed to connect to your WiFi:
- ① Maybe you have entered wrong WiFi password.
 - ② Device is too far away from your WiFi. Please take it closer.
 - ③ Device can not be added to the 5G-wifi-router, only the 2.4G-wifi is OK.
 - ④ Make sure your router is MAC-open.

If still failed, try to open a mobile hot spot and add again.

WiFi LED quickly blinks twice every second:

Device has connected to WiFi but failed to connect to server. Please check your network connectivity.

Scan the user guide to read EWelink works with Amazon Echo, Google Home and Google Nest tutorials.



Scan to download EWelink free APP



Scan to read the detailed user guide

FCC Warning

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:
 This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



When installing the product, make sure that the product's input cord is disconnected to prevent electric shock.



1. Watch out for electric-shock.
2. Please note the antenna and wire terminal with strong electricity.
3. Please consult a professional to install.
4. Install the product in a place that is out of reach during the normal use.