





Restrict Band NVNT ac40 5755MHz Ant1 Peak




Restrict Band NVNT ac40 5755MHz Ant1 Average






Restrict Band NVNT ac40 5795MHz Ant1 Peak




Restrict Band NVNT ac40 5795MHz Ant1 Average






Restrict Band NVNT ac80 5775MHz Ant1 Peak




Restrict Band NVNT ac80 5775MHz Ant1 Average






Restrict Band NVNT ac80 5775MHz Ant1 Peak




Restrict Band NVNT ac80 5775MHz Ant1 Average






Restrict Band NVNT ax20 5745MHz Ant1 Peak




Restrict Band NVNT ax20 5745MHz Ant1 Average






Restrict Band NVNT ax20 5825MHz Ant1 Peak




Restrict Band NVNT ax20 5825MHz Ant1 Average






Restrict Band NVNT ax40 5755MHz Ant1 Peak




Restrict Band NVNT ax40 5755MHz Ant1 Average






Restrict Band NVNT ax40 5795MHz Ant1 Peak




Restrict Band NVNT ax40 5795MHz Ant1 Average








Restrict Band NVNT ax80 5775MHz Ant1 Peak




Restrict Band NVNT ax80 5775MHz Ant1 Average






Restrict Band NVNT ax80 5775MHz Ant1 Peak



Restrict Band NVNT ax80 5775MHz Ant1 Average





### E.5 Frequency Stability


Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	n40	5755	Ant0	5755	0	0	25	Pass
NVNT	n40	5795	Ant0	5795	0	0	25	Pass
NVNT	ac20	5745	Ant0	5745.02	20000	3.48	25	Pass
NVNT	ac20	5785	Ant0	5784.98	-20000	-3.46	25	Pass
NVNT	ac20	5825	Ant0	5825	0	0	25	Pass
NVNT	ac40	5755	Ant0	5755	0	0	25	Pass
NVNT	ac40	5795	Ant0	5795	0	0	25	Pass
NVNT	ac80	5775	Ant0	5775	0	0	25	Pass
NVNT	ax20	5745	Ant0	5745	0	0	25	Pass
NVNT	ax20	5785	Ant0	5785	0	0	25	Pass
NVNT	ax20	5825	Ant0	5825	0	0	25	Pass
NVNT	ax40	5755	Ant0	5755	0	0	25	Pass
NVNT	ax40	5795	Ant0	5794.96	-40000	-6.9	25	Pass
NVNT	ax80	5775	Ant0	5775	0	0	25	Pass






Test Graphs

Freq. Stability NVNT n40 5755MHz Ant0




Freq. Stability NVNT n40 5795MHz Ant0






Freq. Stability NVNT ac20 5745MHz Ant0




Freq. Stability NVNT ac20 5785MHz Ant0






Freq. Stability NVNT ac20 5825MHz Ant0




Freq. Stability NVNT ac40 5755MHz Ant0








Freq. Stability NVNT ac40 5795MHz Ant0



Freq. Stability NVNT ac80 5775MHz Ant0











Freq. Stability NVNT ax20 5825MHz Ant0




Freq. Stability NVNT ax40 5755MHz Ant0






Freq. Stability NVNT ax40 5795MHz Ant0



Freq. Stability NVNT ax80 5775MHz Ant0





Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	n40	5755	Ant1	5755.04	40000	6.95	25	Pass
NVNT	n40	5795	Ant1	5795.04	40000	6.9	25	Pass
NVNT	ac20	5745	Ant1	5745	0	0	25	Pass
NVNT	ac20	5785	Ant1	5785.02	20000	3.46	25	Pass
NVNT	ac20	5825	Ant1	5825	0	0	25	Pass
NVNT	ac40	5755	Ant1	5755	0	0	25	Pass
NVNT	ac40	5795	Ant1	5795	0	0	25	Pass
NVNT	ac80	5775	Ant1	5775	0	0	25	Pass
NVNT	ax20	5745	Ant1	5745	0	0	25	Pass
NVNT	ax20	5785	Ant1	5785	0	0	25	Pass
NVNT	ax20	5825	Ant1	5825	0	0	25	Pass
NVNT	ax40	5755	Ant1	5755	0	0	25	Pass
NVNT	ax40	5795	Ant1	5795.04	40000	6.9	25	Pass
NVNT	ax80	5775	Ant1	5775	0	0	25	Pass




Shenzhen LCS Compliance Testing Laboratory Ltd.  
 Add: 101, 201 Bldg A & 301 Bldg C, Juji Industrial Park Yabianxueziwei, Shajing Street, Baoan District, Shenzhen, 518000, China  
 Tel: +(86) 0755-82591330 | E-mail: webmaster@lcs-cert.com | Web: www.lcs-cert.com  
 Scan code to check authenticity




Test Graphs

Freq. Stability NVNT n40 5755MHz Ant1




Freq. Stability NVNT n40 5795MHz Ant1








Freq. Stability NVNT ac20 5745MHz Ant1




Freq. Stability NVNT ac20 5785MHz Ant1










Freq. Stability NVNT ac40 5795MHz Ant1



Freq. Stability NVNT ac80 5775MHz Ant1













Freq. Stability NVNT ax20 5825MHz Ant1



Freq. Stability NVNT ax40 5755MHz Ant1








Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	n40	5755	Ant2	5755	0	0	25	Pass
NVNT	n40	5795	Ant2	5795	0	0	25	Pass
NVNT	ac20	5745	Ant2	5745.02	20000	3.48	25	Pass
NVNT	ac20	5785	Ant2	5785	0	0	25	Pass
NVNT	ac20	5825	Ant2	5825	0	0	25	Pass
NVNT	ac40	5755	Ant2	5754.96	-40000	-6.95	25	Pass
NVNT	ac40	5795	Ant2	5795	0	0	25	Pass
NVNT	ac80	5775	Ant2	5775	0	0	25	Pass
NVNT	ax20	5745	Ant2	5745	0	0	25	Pass
NVNT	ax20	5785	Ant2	5785	0	0	25	Pass
NVNT	ax20	5825	Ant2	5825	0	0	25	Pass
NVNT	ax40	5755	Ant2	5755	0	0	25	Pass
NVNT	ax40	5795	Ant2	5795.04	40000	6.9	25	Pass
NVNT	ax80	5775	Ant2	5775	0	0	25	Pass








Test Graphs

Freq. Stability NVNT n40 5755MHz Ant2




Freq. Stability NVNT n40 5795MHz Ant2








Freq. Stability NVNT ac20 5825MHz Ant2




Freq. Stability NVNT ac40 5755MHz Ant2








Freq. Stability NVNT ac40 5795MHz Ant2







Freq. Stability NVNT ac80 5775MHz Ant2













### E.6 Duty Cycle


Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5745	Ant0	96.15	0.17	0.72
NVNT	a	5785	Ant0	96.14	0.17	0.72
NVNT	a	5825	Ant0	96.15	0.17	0.72
NVNT	n20	5745	Ant0	95.86	0.18	0.77
NVNT	n20	5785	Ant0	95.79	0.19	0.77
NVNT	n20	5825	Ant0	95.77	0.19	0.77
NVNT	n40	5755	Ant0	91.92	0.37	1.57
NVNT	n40	5795	Ant0	91.77	0.37	1.57
NVNT	ac20	5745	Ant0	89.57	0.48	2.08
NVNT	ac20	5785	Ant0	89.55	0.48	2.08
NVNT	ac20	5825	Ant0	89.39	0.49	2.08
NVNT	ac40	5755	Ant0	82.33	0.84	3.83
NVNT	ac40	5795	Ant0	82.33	0.84	3.83
NVNT	ac80	5775	Ant0	72.68	1.39	6.71
NVNT	ax20	5745	Ant0	89.39	0.49	2.08
NVNT	ax20	5785	Ant0	88.27	0.54	2.33
NVNT	ax20	5825	Ant0	88.48	0.53	2.33
NVNT	ax40	5755	Ant0	88.17	0.55	2.35
NVNT	ax40	5795	Ant0	88.38	0.54	2.35
NVNT	ax80	5775	Ant0	88.03	0.55	2.43






Test Graphs

Duty Cycle NVNT a 5745MHz Ant0




Duty Cycle NVNT a 5785MHz Ant0










Duty Cycle NVNT a 5825MHz Ant0



Duty Cycle NVNT n20 5745MHz Ant0













Duty Cycle NVNT ac20 5745MHz Ant0







Duty Cycle NVNT ac20 5785MHz Ant0

















Duty Cycle NVNT ax20 5825MHz Ant0



Duty Cycle NVNT ax40 5755MHz Ant0








Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5745	Ant1	96.15	0.17	0.72
NVNT	a	5785	Ant1	96.15	0.17	0.72
NVNT	a	5825	Ant1	96.08	0.17	0.72
NVNT	n20	5745	Ant1	95.85	0.18	0.77
NVNT	n20	5785	Ant1	95.85	0.18	0.77
NVNT	n20	5825	Ant1	95.85	0.18	0.77
NVNT	n40	5755	Ant1	91.92	0.37	1.57
NVNT	n40	5795	Ant1	91.92	0.37	1.57
NVNT	ac20	5745	Ant1	89.39	0.49	2.08
NVNT	ac20	5785	Ant1	89.39	0.49	2.08
NVNT	ac20	5825	Ant1	89.39	0.49	2.08
NVNT	ac40	5755	Ant1	82.02	0.86	3.85
NVNT	ac40	5795	Ant1	82.33	0.84	3.83
NVNT	ac80	5775	Ant1	72.68	1.39	6.71
NVNT	ax20	5745	Ant1	88.48	0.53	2.33
NVNT	ax20	5785	Ant1	88.48	0.53	2.33
NVNT	ax20	5825	Ant1	88.45	0.53	2.33
NVNT	ax40	5755	Ant1	88.38	0.54	2.35
NVNT	ax40	5795	Ant1	88.38	0.54	2.35
NVNT	ax80	5775	Ant1	88.03	0.55	2.43






Test Graphs

Duty Cycle NVNT a 5745MHz Ant1




Duty Cycle NVNT a 5785MHz Ant1








Duty Cycle NVNT a 5825MHz Ant1







Duty Cycle NVNT n20 5745MHz Ant1































Duty Cycle NVNT ax40 5795MHz Ant1



Duty Cycle NVNT ax80 5775MHz Ant1








Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5745	Ant2	96.15	0.17	0.72
NVNT	a	5785	Ant2	96.15	0.17	0.72
NVNT	a	5825	Ant2	96.15	0.17	0.72
NVNT	n20	5745	Ant2	73.21	1.35	6.54
NVNT	n20	5785	Ant2	72.73	1.38	6.58
NVNT	n20	5825	Ant2	73.21	1.35	6.54
NVNT	n40	5755	Ant2	91.77	0.37	1.57
NVNT	n40	5795	Ant2	91.77	0.37	1.57
NVNT	ac20	5745	Ant2	62.75	2.02	10.42
NVNT	ac20	5785	Ant2	62.75	2.02	10.42
NVNT	ac20	5825	Ant2	63.4	1.98	10.31
NVNT	ac40	5755	Ant2	82.33	0.84	3.83
NVNT	ac40	5795	Ant2	82.02	0.86	3.85
NVNT	ac80	5775	Ant2	72.55	1.39	6.76
NVNT	ax20	5745	Ant2	88.45	0.53	2.33
NVNT	ax20	5785	Ant2	88.27	0.54	2.33
NVNT	ax20	5825	Ant2	88.45	0.53	2.33
NVNT	ax40	5755	Ant2	88.17	0.55	2.35
NVNT	ax40	5795	Ant2	88.38	0.54	2.35
NVNT	ax80	5775	Ant2	87.85	0.56	2.43






Test Graphs

Duty Cycle NVNT a 5745MHz Ant2




Duty Cycle NVNT a 5785MHz Ant2










Duty Cycle NVNT a 5825MHz Ant2





Duty Cycle NVNT n20 5745MHz Ant2













Duty Cycle NVNT ac20 5825MHz Ant2




Duty Cycle NVNT ac40 5755MHz Ant2






Duty Cycle NVNT ac40 5795MHz Ant2




Duty Cycle NVNT ac80 5775MHz Ant2








Duty Cycle NVNT ax20 5745MHz Ant2




Duty Cycle NVNT ax20 5785MHz Ant2






Duty Cycle NVNT ax20 5825MHz Ant2




Duty Cycle NVNT ax40 5755MHz Ant2





Duty Cycle NVNT ax40 5795MHz Ant2



Duty Cycle NVNT ax80 5775MHz Ant2

