


User manual

Manufacturer: FLUENT AUDIO INC

Address: 8362 TAMARACK VILLAGE SUITE# 119-252 WOODBURY, MINNESOTA 55125 USA



1. POWER ON/OFF button
2. Language button
3. Play/Pause button
4. Volume and channel buttons
5. Backward and Forward buttons

OPERATIONS

1. POWER ON

Press the PWR button to turn on the transmitter. It takes a few seconds for the transmitter to read the mp3 files. After reading the mp3 files, the display will show the current mp3 file number then you may start use the transmitter.

2. NORMAL SETUP

Press the LANGUAGE button to scroll through the language list.

Press the Volume UP or Volume Down button to adjust the volume.

Press digits 0-9 to input the mp3 number (001-999).

Press the >|| (play/stop) button to play or stop a mp3 file.

Press the >>| or |<< (forward or backward) button to forward or backward.

3. CHANNEL SETUP

In OFF status, press the Volume Down and POWER button to enter channel setting page.

Then press the Volume UP or Volume Down buttons to change the channel.

4. LED Status

Green: Power ON

Blue: Receiving signal from transmitter

Red: charging

Red off: charging complete

FCC WARNING

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.