

材质：105g双铜，双面单黑印刷，折页（风琴折）

展开尺寸：280x89mm，折后尺寸：70x89mm

正面



ANC100 User Manual

Congratulations on your purchase and thank you for your use of our Bluetooth Active Noise Canceling Headphone. In order to start quickly, please read the user guide carefully.


#### Caution

1. Please turn off the headphone and put it into box to avoid damage, scratches or bracket deformation when long time no use. In order to prolong the battery service life, please charge every 6 months.
2. Please charge at first if the headphone is left unused for long time.
3. The battery of headphone is original and please don't change it by yourself.
4. Please keep the headphone under dry place.
5. Please don't put this product into the environment with temperature over than 60 C or into fire to avoid battery blast accident.
6. Please don't bent or twist the bracket to avoid deformation.
7. Please don't tear down ear-cushions by un-professional person.
8. Don't adjust the volume to a very high level and continued play. If tinnitus occurs, please turn the volume down or stop playing, do not turn the volume up suddenly. Please slowly turn up the volume to avoid hearing damage caused by high volume.
9. Do not use the headphone in dangerous place or place where cannot hear the outside sound.

#### Included:

The packing contains the following parts:

- \* Bluetooth Active Noise Canceling Headphone X 1
- \* Manual X 1
- \* 3.5mm – 3.5mm audio Cable X 1
- \* USB C Charging Cable X 1



#### Charge the Battery

The headphone contains a USB C cable that can be connected to your computer or other device made for USB charging. Connect the cable to headphone and your computer or other devices made for USB charging. The indicator light will be red while charging. Once fully charged, the indicator light will turn off. Charge time is about 1-2 hours on an empty battery.

#### Active Noise Cancelling On

Push the ANC button. Green LED light will turn on. The ANC function is available at both Wired and Wireless condition.

#### Active Noise Cancelling Off

Push the ANC button. Green LED light will turn off. The ANC function must be switched off by manual operation.

#### Bluetooth Switch On

To switch on, press and hold the MFB about 2 seconds, blue light on, there is a tone "Power on", "pairing".

#### Bluetooth Switch Off

To switch off, press and hold the MFB about 2 seconds, there is a tone "Power off".

反面

#### Pairing

Activate the Bluetooth feature on your phone or Bluetooth devices, and set it to search for Bluetooth devices. Select "ANC100" from the list of found devices on your phone or Bluetooth devices. When successfully connected, there is a tone "connected", the blue light turns to continuously lighting.

The headphone that has been previously paired with another device will automatically connect with the device if the device is power on and within connecting range, if not, the headphone will enter standby mode.

#### Adjust the volume

**Volume up:** Click the volume + to increase volume. When the volume reaches to Maximum volume, there is a warning tone "beep, beep, beep".

**Volume down:** Click the volume - to decrease volume. When the volume reaches to Minimum volume, there is a warning tone "beep, beep, beep".

#### Calls

**Redial calls:** Double click the MFB twice to call the last number in the call list.

**Answer/Hang up calls:** Click the MFB to answer/hang up it.

**Reject calls:** Press and hold about 1 second to reject the call.

#### Switch songs

**Next song:** Press and hold the volume +.

**Previous song:** Press and hold the volume -.

#### Play/Pause songs

Click MFB to play/Pause songs.

#### Activate Voice assistant

Thrice click MFB to activate voice assistant function.

#### Disconnect the Headphone

To disconnect the headphone from your device, switch off the headphone, or disconnect it in Bluetooth menu of your device. There is a tone "disconnected"

#### Reconnect the headphone

To connect the headphone to the phone or Bluetooth devices that you have last used with it, switch on the headphone, or make the connection in the Bluetooth menu of your device.

#### Passive Mode

You can use ANC100 as a wired headphone. Simply connect the audio cable to headphone and your mobile phone.

#### Low Battery Warning

At power on condition, when battery voltage is lower than 3.4V, there will be a warning "battery low".

#### Power-Off at Low Battery Condition

At power on condition, when battery voltage is lower than 3.3V, the headphone will switch off automatically.

#### FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

#### Specification:

|                          |   |
|--------------------------|---|
| Bluetooth version        | V5.1  |
| Active noise reduction   | up to 20±5dB  |
| Radio Frequency coverage | 2.402GHZ~2.480GHZ                                       |
| Support                  | HSP,HFP ,A2DP and AVRCP                                 |
| Transmit Range           | about 10m (barrier free)                                |
| Frequency Response       | 20Hz-20KHz  |
| Driver unit              | 40mm  |
| Impedance                | 32Ω   |
| Headphone Sensitivity    | 98dB±3dB  |
| Microphone sensitivity   | -42dB   |
| Battery                  | Rechargeable li-ion battery; 3.7V, 250mAh               |
| Charge                   | Computer USB interface, output DC 5V/1A charger         |
| Charging time            | 1-2 hours   |
| Operate hours            | up to 10 hours (battery saturation, with BT and ANC on) |
| Standby time             | up to 200 hours (battery saturation)                    |