



正面 (Front)

**FCC STATEMENT :**  
 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
 (1) This device may not cause harmful interference, and  
 (2) This device must accept any interference received, including interference that may cause undesired operation.  
**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
 Reorient or relocate the receiving antenna.  
 Increase the separation between the equipment and receiver.  
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
 Consult the dealer or an experienced radio/TV technician for help.  
**FCC Radiation Exposure Statement:**  
 The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

If you see the percentage is flashing, the battery status is less than 5%. Please recharge the power bank.  
**Recharging your power bank:**  
 To recharge your power bank, use the supplied USB cable to connect its USB-C port to a USB wall charging adapter. While recharging the power bank, the last digit of the percentage will blink. If there is one digit flashing, the charging is not completed. Once the power bank is fully charged, the 100% is displayed.  
 The green charging icon in LED will light up once you enter fast charging mode.  
 NOTE: For best results, do not connect the power bank to a computer's USB port. We recommend using a wall charging adapter that supports fast charging protocols such as QC or PD.  
**Wireless Charging:**  
 Press and release the button, when the red LED remains illuminated, place your smartphone that supports wireless charging on the charger surface, the blue LED indicator will light up once the unit enters wireless charging mode.  
 To stop the wireless charging function, press the button twice quickly or simply remove the smartphone.  
 If the smartphone that supports wireless charging is not detected within 30s, the unit will automatically turn off the wireless output.  
 It will automatically turn off if no load is detected within one minute.

This wireless charger can charge smartphones with non-metal protective case or silicone covers that are no thicker than 6mm.  
**Security advice:**  
 Attention  
 -Incorrect usage can cause explosions / danger of chemical burns.  
 -Damaged batteries can cause chemical burns when they come in contact with human skin.  
 -Do not disassemble the item.  
 -Never throw the item or parts of it into fire.  
 -Never expose the item to high temperature changes Hot/Cold, humidity or liquids.  
 -Do not use if the items or parts of it are damaged.  
 -Store in a clean and dry space.  
 -To maintain battery good health, the item should be recharged every 6 months.  
 Battery will loose capacity when stored without charging.  
 -If the product gets very hot, please disconnect the item and do not use it.  
 -Do not put any bare metal objects on the surface of wireless charger when it is operating.

背面 (Back)

180 x 90mm 70g书纸 双面印刷 对折2次

标准说明书	JMTek	图号	MPB500-SMS-JMT001	版次	第1版	材料		颜色		单位	mm
		型号	MPB500	日期	231116	设计	Steven	批准		客户回签	
		料号		第三角度投影				第 1 张 共 1 张			