

Wireless Power Charger Instruction Manual

Congratulations on your purchase of the Wireless Power Charger.

To ensure a long service life and optimum functionality of the product we recommend that you read this manual carefully.

Package Content

Wireless Charger *1; USB Cable *1; User Manual *1

Specifications

Input (Micro port or Type-C port): DC 5V/2A; DC 9V/1.67A

Wireless Output: DC 5V/1A (5W); DC 9V/1.1A (10W)

USB Output: DC 5V/1A

Charging distance ≤6mm

Type-C port is only used for Input

General information

1. This charger works with all Qi-compatible devices (please make sure your device is Qi-compatible)
2. Devices are available with built-in or external wireless charging receivers.
3. For normal operation, no weaker than DC 5V, 2A charger is required.
4. For a fast wireless charging mode, use the Quick Charger 2.0/3.0 compatible charger and compatible smartphones.
5. This wireless charger can charge smartphones with non-metal protective case or silicone covers that are no thicker than 6mm.

Instructions

1. Connect the wireless charger with the included USB charging cable or another good performance Type-C charging cable to the wall charger and plug the charger into an electronic socket, the red led will light up.
2. Place the smartphone with the display facing up on the centre of the wireless charger or adjust the placement position until the charging process starts, the blue led lights up.
3. To save energy, unplug the charger when not in use.

4. When the smartphone is fully charged, remove it from the wireless charger. When the charging is completed, your smartphone will indicate that the battery is full. (check the smartphone's battery status using the charging icon displayed on the screen)
5. To charge other device, plug the USB cable into the USB port and connect the other end with your device, when this wireless charger is powered with wall charger.

General usage tips

1. Do not place any metal objects between the smartphone and the wireless charger.
2. To ensure more effective charging, remove protective cases.
3. Charging time depends on battery capacity, phone input specifications, current phone energy consumption, phone position on the wireless charger, charging distance, etc.

Possible causes of wireless charging problems

1. Your device is not compatible with the Qi wireless charging standard.
2. Your device is placed on the wireless charger in a wrong position. See the manual of your smartphone to find the exact place of the built-in Qi wireless charging receiver.
3. A protective case of the smartphone or another object on the back of the smartphone is blocking the charging process.
4. The USB charger is too weak, defective or unplugged from the electric socket.
5. The charging cable is unplugged, broken or too weak for correct functioning.

Safety information

1. Do not drop or cause an impact on the device.
2. Do not disassemble, modify or repair your device.
3. Keep away from humidity and heat.
4. Keep it beyond the reach of children.

Precaution!

1. Metal objects placed on top of charging devices might result malfunction of the item and damage the charging device on top of it.
2. Do not operate the item on top of any metal work table or surface.

FCC ID: 2APU5-WPC420-10W

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.