

CQL1682-B Bluetooth Speaker Instruction Manual (Read before proceeding)

Power:

- Please charge your Bluetooth speaker fully before its first use.
To charge the battery:
- Using a Micro USB Charging Cable (included), insert the USB power cable into the micro USB port located **at the side** of the speaker. Connect the other end of the USB cord into a powered USB source such as a computer, laptop or USB AC adapter.
- When your Bluetooth speaker is charging, the indicator light will turn red.
- Once your Bluetooth speaker is fully charged, the red light will turn off.

Playing Music via Bluetooth

- Turn your Bluetooth speaker on by sliding the power switch located **at the side** of the speaker to 'ON' position. The Bluetooth indicator light will start flashing blue quickly.
- Make sure the Bluetooth function on your device is turned on.
- Search the speaker named, "SB-01".
- Once you have selected the speaker, your device will pair without a password. (If your device prompts for a password, enter the password "0000".)
- Once your speaker is paired, the blue indicator light will begin to flash slowly.
- Start playing music on your device. Make sure that you keep your device within a 33 feet range of your Bluetooth speaker.
- Adjust the volume of your device to a comfortable level.
- **Control play/pause, volume up/next track and volume down/previous track either on your connected device or by the buttons on the fabric of the speaker.**
- Turn off the unit when not in use.

Button Control:



- This button is for microphone function **and** voice assistant function.
- First, pair the speaker with your mobile phone via Bluetooth.
- When the phone call is coming in, **press** this button to answer the phone.
- When the call is coming in, **long press this button** to refuse the phone call.
- When you are having a phone conversation, to end the phone conversation, **press** this button to end it.
- When there is no phone call, **quick press this button twice** to dial the latest phone call.

- **Long press** this button to activate the Google/siri function. After a tone is heard, start

speaking. To speak again, long press this button to activate it again.



: Press it for next track. Long press it to increase the volume.



: Press it for previous track. Long press it to decrease the volume.



: This button is for pause/play only. Press it one time to pause/play your music.

Caution:

- This is not a toy. Please keep away from children.
- Please keep away from water / heat.
- Low power may cause poor connection even no working of Bluetooth.
- Do not overcharge the battery.
- Battery pack shall not be exposed to excessive heat such as sunshine, fire or the like.

Note: this speaker is waterproof to IPX4 standard only.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver

is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.