

DISNHUMD/CQL1893-B Humidifier LED Bluetooth Speaker

Instruction Manual (Read before proceeding)

Power:

● Humidifier:

Plug the small connector of the included USB power cable into the USB power port on the back of unit

Plug the large connector into a USB power port or into a compatible 5V USB adaptor (not included) and plug into a wall socket.

The LED indicator will turn red when the speaker is connected to a power source.

● Bluetooth Speaker:

The speaker is powered by USB or built-in battery.



To charge the battery

Insert the small connector of the supplied micro-USB power cable into the USB power port on the back of the speaker.

Insert the large connector into the USB port on a computer or a 5V USB adapter (not included) and plug into a wall socket

The LED indicator will turn red when the speaker is connected to a power source.

Diagram:



1. Humidifier button
2. LED Power Indicator
3. Micro USB power port
4. Bluetooth Power Switch

Set Up the Humidifier

- Remove the cover from the unit
- Take of humidifier stick apart then put the spring into the bottom of stick.
- Wet the entire sponge wick and then place it inside
- Snap the humidifier stick back to the top.

*Note: Use only clean water. Do not use essential oils, as they can block humidification or damage the humidifier
Do not lose the spring

Using the Humidifier Stick

- Set up the humidifier and connect to power.
 - Fill the water tank with clean water to the max volume level
 - Press the Humidifier button to turn it On in Continuous Mist Mode
 - Press humidifier button again to enter Intermittent Mist Mode
 - Press humidifier button 3rd time to power off
- ✧ The humidifier will automatically power OFF after 4 hours in Continuous Mist Mode, or 6 hours in intermittent Mist Mode.

Warning: To avoid damage to the unit, make sure the water is above the bottom of the humidifier stick

Playing Music via Bluetooth

- Turn your Bluetooth speaker on by sliding the power switch located on the back of the unit to the ON position to activate the Bluetooth function.
- A tone will be heard to indicate the speaker entering pairing mode and searching for your Bluetooth device.
- Make sure the Bluetooth function on your device is turned on.
- Search the speaker named "XXX".
- Once you have selected the speaker, your device will pair without a password. (If your device prompts for a password, enter the password"0000".)
- Start playing music on your device. Make sure that you keep your device within a 33 feet range of your Bluetooth speaker.
- Adjust the volume of your device to a comfortable level.
- Turn off the unit when not in use.

Light Operation

- Power the Bluetooth on the LED light will cycle through different colors automatically.
- Turn the Bluetooth power switch off to turn off the light.

Caution:

- This is not a toy. Please keep away from children.
- Please keep away from water / heat.
- Low power may cause poor connection even no working of Bluetooth.
- Do not overcharge the battery.
- Battery pack shall not be exposed to excessive heat such as sunshine, fire or the like.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction