2668DNUSER MANUAL

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the followingmeasures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2APUT-2668DN

1.Technical Information:

Item	Parameter	Item	Parameter
Input Voltage	DC 9-12V	Output Format	Standard Wiegand
Working Current	≦ 100mA	Color	Black
Frequency	13.56MHz	Dimensions	Approx. 85 x 75 x 18mm
Support Card Type	Mifare one (S50,S70), MifareDesFire, NTAG Card		

2. Cable Terminal Information:

No.	Color	Symbol	Description	
1	Red	12V	Power input, connect to control system 12V output terminal	
2	Black	GND	Connect to control system GND terminal	
3	Green	D0	Wiegand data output, connect to control system D0 input terminal	
4	White	D1	Wiegand data output, connect to control system D1 input terminal	
5	Blue	LED	LED indicator control terminal, active low	
6	Yellow	BEEP	Beep control terminal, active low	
7	Orange	26/34	Wiegand format select (Optional function)	

3. External View

