
Size: 21x10 cm



Power Bank 's Charging Method

1) When charging your portable devices: Connect the USB charging cable that came with your portable device to the USB output port; connect the other end of the USB charging cable to your portable device and turn it on. your portable device will begin charging immediately.

 When recharging: Connect the Micro USB Charging Cable to the Micro USB recharger port; connect the other end of the Micro USB charging cable to a powered USB port.

Wireless Charger's Charging Method

- Connect wireless charging pad to a power source via included micro USB cable and turn it on. Charging pad entering standby mode.
- Place your protable device in the center area of the charging pad, charging begins.

Product specs:

Product model: #AB0001

Main functions: wireless charging transmitter& power bank;

Standard version: WPC - 1.1;

Charging type: one-on-one charge corresponding area; Power bank Input Specs: DC: 5V/2A; Output: DC: 5V/2A Wireless charger luput Specs: 5V/2A; Output: DC 5V/1A

Battery Capacity: 6000mAh Effective Distance: 4 to 6 MM; Conversion efficiency: ≥70%; Charging methods: induction model; Working frequency: 111.5-205 KHZ;

Accessories: USB cable; Wireless charging pad; Packing box, and instruction sheet.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.