


Size: 7x10.5cm

Wireless Charger Instruction Sheet

The Diagram of Installation



Wireless Charger's Charging Method

- 1) Connect wireless charging pad to a power source via included micro USB cable. When the charging pad enters standby mode the indicator light will flash white.
- 2) Place your portable device in the center area of the charging pad. When charging begins the indicator light will turn solid white.

Product specs:

Product model:

Main Functions: Wireless Charging Transmitter;

Standard Version: WPC - 1.1;

Charging Type: One-on-one charge corresponding area;

Input Specs: DC: 5V/1.5A ;

Output Specs: 5V, up to 900mA output

Effective Distance: 4 to 6 MM ;

Conversion Efficiency: $\geq 70\%$;

Charging Methods: Induction Model;

Working Frequency: 111.5-205 kHz;

Accessories: USB cable; Wireless charging pad; Packing box, and instruction sheet.

The distance between user and products should be no less than 20 cm.

Warning!

This wireless charger is designed to charge Qi compatible mobile phones. Not for use with AirPods[®], Airpod Pros[®] or other earphones with wireless charging cases. AirPods is a trademark of Apple Inc., registered in the U.S. and other countries

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment