
UL Listed 10000 mAh Wireless Power Bank



Model: AB0495-B Item No. 32526

Features:

- 1. Wireless Charging Surface
- 2. LED Indicator
- 3. ON/OFF Button
- 4. USB-A Output
- 5. Type-C Input
- 6. Micro Input

What's included:

- 1 x 10000 mAh Wireless Powerbank
- 1 x USB-A to Type C Cable
- 1 x Instruction Manual

Tech Specifications Micro Input: DC 5V/2.1A

Type-c Input: DC 5V/2:1A
Type-c Output: DC 5V/2:1A
USB-A Output: DC 5V/2:1A
Wireless output: 5V/1A,9V/1.1A
Total Output (max): 10.5W
Battery/Cell capacity: 37Wh, 3.7V/10000mAh
Product capacity (Wirelss): 21Wh, 5V/550/mAh
Product capacity (Wirelss): 21Wh, 5V/4200mAh

LED Indicators

 ON/OFF Button: Press once to view the remaining power capacity.

INSTRUCTIONS:

- 1. Charging the Powerbank:
- Charge the powerbank fully before usage.
 Connect the provided charging cable to a
- Connect the provided charging cable to a power source and to the Type-C port on the powerbank(3).Or use your own micro cable to connect Micro-USB port(5) to charge.
- Once connected the LED Indicator will begin to flash when charging, once fully charged LED will turn solid.
- Charging mobile phones and other electronic devices (like some laptops):
- Connect the charging cable to your mobile phone/device using the appropriate connector. Connect the USB or Type-C part of the cable into either USB Output(4 or Type-C(3) port. LED Indicator will illuminate when chargina.
- Remove the cable from your mobile device when it is fully charged.
- 3. Wireless Charging Function:
- Press the Powerbank ON/OFF button(1) to turn on the wireless charging function, LED indicator will glow green when in standby mode.
- Place wireless charging supported mobile device on the charging surface/suction pad, LED will glow red when device is charging
- Phone will begin to charge automatically, Wireless Charging LED will turn off when the device is fully charged.
- ** Note: When wireless charging, if the LED indicator will flashes the device is either NOT a wireless charging device or there is an object between the device and charging surface interfering with the charging. process.

SAFETY PRECAUTIONS:

- WARNING-When using this product, basic precautions should always be followed:
- 1. Read all the instructions before use.
- Never store or use this product in temperatures below 32°F (0°C) or above 115°F (45°C).

- Do not overcharge your phone. The unit may become hot under excessive use. Remove your phone once it is fully charged. Never charge your phone for more than 7 hours at a time.
- The unit will only achieve full performance after 2 or 3 completed charge and discharge cycles.
- To reduce the risk of injury, close supervision is required when the product is used near children.
- 6. Do not expose the device to moisture.
- Do not use the device in excess of its output rating. Overload outputs above the rating may result in a risk of fire or injury.
- Do not use the device if damaged or modified.
- Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
- Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
- Do not expose the device to fire or excessive temperatures. Exposure to fire or temperatures above 104°F (40°C) may result in explosion.
- To ensure product safety, ensure that qualified service professionals use only identical replacement parts.
- 13. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.

FCC Statement:

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

- * Caution: Risk Of Fire And Burns
- * Warning: See Instruction Manual Before Use.



Importer for USA and Canada Distributed by Koozie Group 14421 Myerlake Circle Clearwater, FL 33760 USA



FSC® C170226

16 mm

10.4mm

FSC
MIX
Paper I Supporting responsible forestry
FSC° C170226

5 mm

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF warning statement: the device has been evaluated to meet general RF exposure requirement , The device can be used in portable exposure condition without restriction.