

WIRELESS CHARGING

Tech Specifications

Input: 5V 2A, 9V 2A

Output: 15W

Instructions

Time set: Tap the clock key on the panel to enter the setting hour mode, then use the "+" and "-" keys to adjust the hour time. Press the clock key to switch minutes. Adjust the minutes with the "+" and "-" keys. After the minute adjustment, press the clock key to switch to the 12-hour system and the 24-hour system. Press the "+" and "-" keys to adjust, and finally press the clock key to save the Settings.

Including 1xCR2032 cell battery, this battery's function: it only keep the accuracy of clock when charging cable is unplugged. The screen will not display the time when charging cable is unplugged, and the time should be reset if you replace the new battery.

Alarm clock set: Tap the alarm key on the panel to enter the setting hour mode, and then use the "+" and "-" keys to adjust the hour time, and then press the alarm key to switch the minute time, and use the "+" and "-" keys to adjust the minute time. After adjustment, press the alarm key to enter the alarm ON or OFF, press the add and subtract keys to adjust, and finally press the alarm button to save the settings.



Warnings:



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The distance between user and products should be no less 20cm