

Don't
Panic!



Timekettle M3 Translator Earbuds **Manual**


English

01

中文

15


Package List




* How to wear: Choose the right size tip for your ears for the best fit and seal.

On/Off

Power On: taking out the earbuds from the charging case, the indicator light flashes green once to indicate that the earbuds are powered on.




Power off: the earbuds will power off automatically after being placed in the charging case.



Bluetooth Pairing

1. The earbuds will automatically enter Bluetooth pairing mode once removed from the charging case, with the status indicator continuously flashing white.
2. Select "Timekettle M3" on the Bluetooth list of the phone to build the connection by accepting the pairing request.



*If the Bluetooth is not paired within 5 minutes, the earbuds will automatically power off.


Reset

You may need to reset the earbuds if you experience connection problems or functionality issues.


1. Put your earbuds in their charging case and wait for the status indicator to turn in solid white.
2. Press the left and right earbuds three times separately to access the reset mode, and the status indicator blinks in alternating flashes of white and green three times to indicate the completion of the reset.
3. Do not remove the earbuds from the charging case during resetting.
4. If the reset is unsuccessful, it is recommended to try again and make sure resets are done on both earbuds.
5. Resetting will erase the Bluetooth pairing history from your device. To reconnect your earbuds to the device, first Remove or Forget the earbuds from the device's Bluetooth memory.

Touch commands

Music mode:



Phone Mode:



*The earbuds indicator: the earbuds indicator light can be switched on and off in the APP settings.

Timekettle APP Download

Timekettle M3 only works with the Timekettle APP. Search "timekettle" on Google Play /APP Store or scan the QR code.



Timekettle



Google Play and the Google Play logo are trademarks of Google Inc.





Apple and the Apple logo are trademarks of Apple Inc.

*Note: UI changes and new feature updates are subject to change without notice, please refer to the latest version of the APP.

Translation feature


1. Open the APP to complete registration and login and allow all access permissions to ensure the translation feature works properly.
2. On Product Selection page, select "Timekettle M3", then enter the Bluetooth pairing page to complete the pairing.
3. Choose the corresponding translation mode for different usage scenarios. For example, Touch Mode is recommended for one-on-one conversations; Listen mode is recommended for simply listening in meetings and classes; Speaker mode is recommended for short conversations during travel with strangers.



Charging

Power Display

The charging time for the case takes (from empty to fully charged): 90 minutes.




Full Battery Power (100%)	●	●	●
High Battery Power (66%~100%)	●	●	⚙
Medium Battery Power (33%~66%)	●	⚙	○
Low Battery Power (0%~33%)	⚙	○	○

Charging the Earbuds

The charging time for the earbuds takes (from empty to fully charged): 75 minutes

The earbuds' indicator lights up in solid white during charging; When fully charged, the earbuds' indicator turns off automatically.



Troubleshooting

● Unable to use the APP translation feature properly

1. Make sure both earbuds are correctly connected to the APP. Note: the translation feature cannot be used with only one earphone connected.
2. Disconnect other Bluetooth devices connected to the phone, such as a smartwatch using the phone's microphone permission at the same time.
3. Close the app and reset the earbuds and reconnect the phone via Bluetooth pairing.

● No sound in one or both earbuds

1. Check if both earbuds are out of battery.
2. Put the earbuds back in the charging case, then take them out again.
3. Reset both earbuds separately and pair them again via Bluetooth.

● Unable to charge the earbuds or no indicator when charging

1. Unable to power on or charge the earbuds Check if there is power in the charging case.
2. Check if the earbuds are correctly placed in the charging case.
3. Make sure the charging cable and power adapter meet the standard specifications.

● The phone is unable to find Bluetooth or the Bluetooth pairing failed

1. Keep the earbuds as close to the phone as possible.
2. Avoid using the earbuds in RF interference environments, such as next to wireless routers, microwave ovens, and other such devices.
3. Place the earbuds back in the Charging Case, then take them out to pair via Bluetooth again.
4. Reset both earbuds separately and pair them again via Bluetooth.
5. If the earbuds are already connected to the phone, Remove or Forget them from the device's Bluetooth memory and repeat steps 3 and 4.

● Unable to switch to music and wake up voice assistant

1. Check the permission setting of the music player and phone.
2. It is recommended to use the phone's default media player to avoid possible system compatibility issues.

* If problems persist during the use, please contact the store where you purchased the product or the official customer service.

Product Information

Model: Timekettle M3

Bluetooth version: 5.2

Power input: 5V=1A

Weight of Earbuds: 5g (one piece)

Weight of charging case (including earbuds): 60g

Charging case battery: 400mAh

Earbud battery: 50mAh (one piece)

Music playback time with Noise Cancellation On:

approximately 6 hours

Music playback time with Noise Cancellation off:

approximately 7 hours

Safety

Please read the following safety and warning information before using M3.

1. Do not use unofficially recommended charging methods to avoid fire, explosion, or other dangers.
2. Do not deliberately drop, burn, penetrate, squeeze, or immerse in liquid to avoid product damages.
3. Do not expose to high temperatures or around heating equipment such as microwaves or ovens.

4. Use the device within the range of 0°C ~ 35°C and store within the range of -20°C ~ 45°C. If the temperature is too high or too low, it will cause the device to malfunction.

5. Timekettle is not responsible for quality issues, product failures, and safety accidents caused by the use of unofficially approved accessories.

Corporate Information

Official Website: www.timekettle.co

Customer Service: support@timekettle.co

Manufacturer: this product is authorized for manufacturing by Shenzhen Timekettle Technologies Co., Ltd.

Address: Room 602, Building 3, Minqi Science Park, Xili Road, Shenzhen, Guangdong Province, China

All rights reserved by Shenzhen Timekettle Technologies Co., Ltd.

Warranty regulations

1.If the product and accessories have any quality issues within 1 year (unless otherwise states by local laws & regulations) and 6 months respectively from the date of purchase, you may be qualified for free repair service with proof of purchase and warranty card.

2.What is NOT covered by the warranty:

- a. Product is worn due to regular usage.
- b. Failure to use in accordance with the instructions.
- c. Damage caused by human or irresistible factors.

3.Repair costs will incur for damages caused by man-made faults, beyond the warranty period, and irresistible factors.

IC STATEMENT

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

FCC ID:2AQ2G-M3 IC:26483-M3 HVIN:M3

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.