



10 11

## 





	Open Mi Home / Xiaomi Home app, and log in your account, tap "+" on the upper right, and then follow prompts to add your device. Note: The version of the app might have been updated, please follow the instructions based on the current app version. * The app is referred to as Xiaomi Home app in Europe (except for Russia). The name of the app displayed on your device should be taken as the default.	Stop Double Stopw can do Note: <sup></sup> Timer,	
	"works with mijia" signifies that the product herein is designed to connect and interact with Mi Home app or Mi Al. Please be noted that the product herein is certified by the app interaction only. Xiaomi and Mijia are not responsible for any of the product manufacturing, safety and regulatory standards, or quality supervision.		
5	Works with Xiaomi Home         Works with Mi Home		

Question/ Problem	Answer/Solution			Error Code		Performance Faults	
	Answer/solution	The screen doesn't	Please refer to the instruction "Insert or	Error Code on		The content displayed on the screen is incomp	plete or the
	for example, after being moved from outdoor to indoor, it takes about 10 minutes for the readings to approach the actual values of the new environment.     If you the a settin assume add the "Loc;       2. When the product is held in hand, the human body will affect the readings, and     add the "Loc;	Replace Battery" of this manual.	the Screen		screen cannot display content.	reen cannot display content.	
			If you use an Android phone, please allow the app to access "Location" in the system settings and turn on the Location service.	F1 The environment temperature exceeded		No response when the button is pressed.	
inaccurate. humar result i and the 3. Check produc		(Scanning Bluetooth devices requires the		the measurement range of the product.	The button cannot be pressed down.		
	and the actual values of the environment. Check if the vent hole at the bottom of the product is clogged. If it is, please clean it	actual values of the environment.     the mobile     If you use Mi He       f the vent hole at the bottom of the     app.     please enter "Se       c is clogged. If it is, please clean it     app.     app.	If you use Mi Home / Xiaomi Home app, please enter "Settings" from "Profile" of the app, then enter "Region", select "Chinese mainland", save and try again.	E2	The sensor is malfunctioning.	The sensor is not working properly.	
	inaccurate.	Readings       outdoor to indoor, it takes about 10 minutes for the readings to approach the actual values of the new environment.         Readings       2. When the product is held in hand, the human body will affect the readings, and result in differences between the readings and the actual values of the environment.         3. Check if the vent hole at the bottom of the	Readings       outdoor to indoor, it takes about 10 minutes         for the readings to approach the actual       values of the new environment.         2. When the product is held in hand, the       add the         inaccurate.       human body will affect the readings, and       add the         result in differences between the readings       and the actual values of the environment.       the mobile         3. Check if the vent hole at the bottom of the       product is clogged. If it is, please clean it       app.	Readings inaccurate.outdoor to indoor, it takes about 10 minutes for the readings to approach the actual values of the new environment.If you use an Android phone, please allow the app to access "Location" in the system settings and turn on the Location service. (Scanning Bluetooth devices requires the "Location" permission on Android.)Readings inaccurate.2. When the product is held in hand, the human body will affect the readings, and result in differences between the readings and the actual values of the environment. 3. Check if the vent hole at the bottom of the product is clogged. If it is, please clean itDifferences between the readings app.If you use Android phone, please allow the app to access "Location" in the system settings and turn on the Location service. (Scanning Bluetooth devices requires the "Location" permission on Android.)If you use Mi Home / Xiaomi Home app, please enter "Settings" from "Profile" of the app, then enter "Region", select "Chinese	Readings       outdoor to indoor, it takes about 10 minutes       If you use an Android phone, please allow         Values of the new environment.       Cannot       settings and turn on the Location service.         2. When the product is held in hand, the       add the       result in differences between the readings       and the actual values of the environment.         3. Check if the vent hole at the bottom of the       product is clogged. If it is, please clean it       app.       If you use an Android phone, please allow       E1	Preadings       outdoor to indoor, it takes about 10 minutes       If you use an Android phone, please allow       If you use an Android phone, please allow         Readings       2. When the product is held in hand, the       add the       settings and turn on the Location service.       Settings and turn on the Location service.       Settings and turn on the Location service.       The environment temperature exceeded         add the       product in       inferences between the readings       add the       product in       The environment temperature exceeded         3. Check if the vent hole at the bottom of the       product is clogged. If it is, please clean it       app.       please enter "Settings" from "Profile" of the       app, then enter "Region", select "Chinese       E2       The sensor is malfunctioning.	suddor to indoor, it takes about 10 minutes for the readings to approach the actual values of the new environment.       If you use an Android phone, please allow the app to access "Location" in the system settings and turn on the Location service. (Scanning Bluetooth devices requires the result in differences between the readings, and result in differences between the environment.       If you use an Android phone, please allow the app to access "Location" in the system settings and turn on the Location service. (Scanning Bluetooth devices requires the roduct in the mobile app.       The environment temperature exceeded the measurement range of the product.       No response when the button is pressed.         Base and the actual values of the environment. 3. Check if the vent hole at the bottom of the product is clogged. If it is, please clean it       If you use Mi Home / Xiaomi Home app, please enter "Settings" from "Profile" of the app, then enter "Region", select "Chinese       E2       The sensor is malfunctioning.       No response when the button is pressed.




## Stop an Alarm When a normal alarm is ringing, click the button on the back of the product to stop the alarm.

back of the product to temporarily stop it, and the alarm will ring again in ten minutes, double-click the button to stop the Snooze. \* When an alarm is ringing, it will stop after 10 minutes without operation.

When an alarm set Snooze is ringing, click the button on the

Turn off All Alarms Press and hold the button on the back of the product for 6 seconds to turn off all alarms. After that, you can press and hold the button for 6 seconds again to restore the previous alarm settings.

Restore Factory Settings Press and hold the button on the back of the product for 12 seconds, the screen will display "88:88", and the factory settings are restored.



 Within 12 months from the date of receipt, if the product has faults listed in the "Performance Faults", after the faults are confirmed by our after-sales service department, the customer can have the maintenance service for free.
 In countries or regions where Qingping Technology (Beijing) Co., Ltd. has not established a branch or after-sales service center, please contact the local seller if you have any quality problems.

## Non-warranty 1. Unauthorized repair, misuse, collision, negligence, abuse, liquid injection, accident, alteration, improper use of accessories not originally supplied with this product. 2. The warranty period has expired. 3. Damage caused by force majeure. 4. The situation does not meet the fault listed in the Performance Faults.

FCC Warning Statement. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.