1 | INSTALLATION

- a. Turn on the computer
- b. Remove the battery lid; Insert the batteries (2 AAA included) into the battery compartment and place back the lid.
- c. Insert the USB receptor into the computer's USB port (Note: the USB nano-receptor can remain permanently connected to your
- d. Use the foldable system to activate/ deactivate the mouse. If folded, the LED will light down and if opened, the LED will light up.

2 I MOUSE OPERATION

- 21 MOUSE OPERATION
 Use the foldable system to torun 0N /0FF
 1. LED: The LED lights up when the mouse is on
 2. The mouse has a power economy mode. When the mouse is not in use [no activity] for 2 minutes, it automatically enters the power economy mode and the LED on the back of the mouse lights down.
 2. To reactive the power propulsely five seconal with a
- 3. To reactivate the mouse simply click or scroll with it.

USB RECEPTOR

- The mouse automatically turns on when the nano-receptor is connected to the computer's USB port.
- 2. When removed the mouse automatically turns off.
- 2. When removed the mouse au
 3. specifications:

 Receptor's interface: USB

 Connectivity: 2.4GHz

 Frequency: 2402-2480Mhz.

 Resolution: 2400 dpi

- Resolution: 2400 dpi
 Consumption: 15mA.

 Max. communication range: up to 10m
 Battery type: 2 AAA batteries [included]
 Compatible with: Windows and Mac 0S.
 To recover the mouse/receptor connection:
 a. Remove and insert back the receptor;
 b. Click on the right and left buttons of the mouse at the same time and within 15 seconds the mouse and receptor will connect.

WARNING:

- If the mouse doesn't work, check the batteries and replace them if necessary.

 The power consumption is reduced if the mouse is used over a white
- surface.

and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

FCC Warning Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested

- - Increase the separation between the equipment and receiver.

Reorient or relocate the receiving antenna.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.