

487*100mm 105g

IP Camera



Included Parts

Full HD Camera
Micro USB Cable
AC Power Supply
Screws & Anchors
Reset Tool
Wall Mount
2-Sided Foam Pad

A Closer Look

1. Micro SD Card Slot
2. LED Indicator Light
3. Lens
4. Microphone
5. Light Sensor
6. Ventilation Holes
7. Speaker
8. Reset Button
9. Micro USB Port

Inserting a Micro SD Card

When properly inserted, you will feel the card will click into place.

*For best results, use a Class 4 or higher Micro SD memory card, up to 32 GB.

Powering On

● (red) = Powered ON
●● (blinking) = Wi-Fi Setup Mode

est. **FIRST**

If You're Having Trouble, We're Here to Help!
Call us 24/7 at 1-855-292-4087
E-mail us at support@alteclansing.com or visit us at alteclansing.com

App Download

iPhone OR Android

Install Altec Smart Security System App

App Setup

Run the Altec Smart Security System App

NOTE: Your IP Camera is supported only on a 2.4GHz Wi-Fi Network. Before setup, please make sure your mobile device is connected to a 2.4GHz Wi-Fi Network.

For more in depth instruction on using the Altec Smart Security System App, please refer to the User Manual that can be accessed by selecting 'Help' in the app's menu option.

Menu

App Setup (continued)

Press to add your camera and follow the app's instructions.

Press to add your speaker and follow the app's instructions.

Troubleshooting

● (blue) = Wi-Fi connected successfully

If the device does not connect in 90 seconds, then reset as per below:

To reset, insert the included reset tool into the reset button. Wait until the LED Indicator Light turns red. Wait approximately 15 seconds for the camera to reboot.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complied with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.