

# S1 user manual

Thank you for choosing S1 product, and we will provide after-sales service worthy of your trust. In order to make you more satisfied with the use of S1 product, we sincerely suggest that you carefully read the instructions below.



## Product parameters

System compatibility: ISO/Android

Bluetooth Version: Bluetooth Version 4.0

Effective distance: about 10 meters

Frequency: 2402-2480 MHz

Battery: removable button battery

Turn the square battery cover on the remote control outward, then release the battery cover, remove or load the button battery into the new "CR1632 3V" button battery, and press the top cover again to use.

Note: please pull out the insulation sheet for the first time, so that the bluetooth remote control can work normally.

#### **Product set using Steps:**

- 1、 Long press the power button for 3 seconds to turn on wireless.
- 2、 Open Wireless on the phone, search for Wireless devices. Click "S1" to connect the Wireless device.
- 3、 The light will flash before connecting. When connected, the light will go out.
- 4、 If connection failed within 90s will enter sleeping mode and the light will turn off. You can press the shutter button to activate.

Reminder: If you meet problem after first use, you just need to deleting the original signal "S1", re-connect the bluetooth of the device.

#### **FCC INFORMATION**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.