
更换遥控器电池 1.蓝牙连接 4.通用冷靴口(可选) 遥控器转至背面,取下遥控器底盖,可更换钮扣电池 (CR1632) 长按遥控器拍照键3秒绿 支架设有通用冷靴口端 灯闪烁进入蓝牙配对状 口,可安装麦克风补光 态,打开手机端进入蓝 灯使用。 **3** >>> 牙搜索状态,在搜索设 备中点击 "Dispho" 连接成功后, 遥控器绿 灯熄灭。 *首次使用,取下后盖去除遥控器电源仓中的隔电片。 5.更换配件 把支架取下来,然后把 2.使用三脚架 螺杆安装。 打开底部三脚架,拉开 1.5m(户外版) 拉杆,把三脚架放在平 稳的水平面上。 警告 操作说明 1. 使用中小心夹手。 2. 本商品请勿让14岁以下儿童玩耍使用,请勿吞食。 3. 请勿自行拆开或改装本产品。 4. 请勿将本产品存放在潮湿环境中。 5. 请勿将产品靠近热源。 3.固定手机 6. 请勿将水或其它液体流入本产品内部,导致本产品损坏。 6.通用1/4英制螺杆 打开手机支架,把手机 支架设有通用1/4英制螺 安全安置在手机支架内 杆,可安装适用的配件使 ,支架部份可360°旋转 使用。



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ISED Statement

- English: This device complies with Industry Canada license - exempt RSS standard(s).

Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES - 3 (B)/NMB - 3(B).

- French: Le présentappareilestconforme aux CNR d'Industrie Canada applicables aux appare ils radio exempts de licence. L'exploitationestautorisée aux deux conditions suivantes: (1) l'a ppareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareildoit accepter tout b rouillageradioélectriquesubi, mêmesi le brouillageest susceptible d'encompromettre le fonct ionnement. L'appareil numérique est conforme à CAN CAN ICES-3 (B) / NMB-3 (B).

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

RF Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used installed and operated with minimum distance 0mm between the radiator and your body.

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF.Cet équipement doit être installé et utilisé avec une distance minimale de 0 mm entre le radiateur et votre corps.