User Manual

Fish logger

1, The Bluetooth board has no key function, power LED blue light flashes, enter Bluetooth pairing mode, open mobile phone Bluetooth, search for Bluetooth device: Fish Logger, click to connect Bluetooth device, device display is connected, blue light is always on, It means pairing is successful.

2. After the device is successfully paired, enter the camera photo interface, and tap the device to open the key.

3. After the device is successfully paired, if you need to change the phone, please turn off the phone Bluetooth, replace the new phone to enable Bluetooth, search for pairing, and refer to the first step.

4, Turn off the phone Bluetooth, the device automatically disconnects, and continues to flash, when the blue light flashes, turn on the phone Bluetooth, it will automatically connect with the device again.

5. Keep the phone Bluetooth enabled, disconnect the power, and the Bluetooth board will be disconnected. Re-energize, the device is turned on, and it will automatically connect to the mobile phone Bluetooth again.

(If the button does not take a picture or freeze during the use of the device, please turn off the power. Use the reference manual section 1 again.)

6, For IOS system phones, and 90% of the mainstream Android system phones on the market.

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.